

Year	Application	Shocks & Strut				Strut Mount	
		Front	Symbol	Rear	Symbol	Front	Rear
Audi							
99-2000	TT					802 070	802 100
BMW							
99-00	323i, 323Ci, 328i, 328Ci (E46)	32D 87A Lt.	Gas		27C 41A		
2001-02	325i, 325Ci, 330Ci (E46)	32D 86A Rt.	Gas				
2001-02	325Ci, 330i, 330Ci (E46)	32D 87A Lt.	Gas		27C 42A		
		32D 86A Rt.	Gas				
2001-02	325iT (E46)				27C 42A		
98-01	540iT (E39)	36A 62A	Strut		376 28D		
98-00	528iT (E39)	36A 60A	Strut		376 27A		
98-00	528iT w/Sport Suspension (E39)	36A 61A	Strut				
98-01	540iT w/Sport Suspension (E39)	36A 63A	Strut				
95-00	528i, 540i w/EDC (E39)					802 056	802 005
00-02	Z3 Roadster 2.5 Liter	32C 02F Lt.	Strut		27B 56F		
		32C 01F Rt.	Strut				
9/86-7/87	735i, iL w/Std. Suspension w/o EDC (E32)						
	Left Side				102 506	Hydromat	
	Right Side				102 505	Hydromat	
94-01	740i, iL, 750i, iL w/o EDC (E38)						
	Left Side				102 495	Hydromat	
	Right Side				105 500	Hydromat	
Buick							
2000-01	Buick LeSabre, Park Avenue					802 859*	802 860
98-99	Buick Rivera					802 859*	802 860
97-99	Buick LeSabre					802 861*	802 708
1997	Buick Park Avenue					802 862*	802 860
Cadillac							
98-2001	Cadillac Seville					802 859*	802 860
97-2001	Cadillac Catera					802 863*	802 864
2000-01	Cadillac Deville					802 865*	802 860
Chevrolet							
2001	Chevrolet Corvette Z-06 w/45mm	030 281			030 282		
2000-01	Chevrolet Lumina, Impala, Monte Carlo					802 857*	802 858
99-2001	Chevrolet Cavalier					802 866*	
97-98	Chevrolet Malibu w/Early Design Rear Strut (3.25" Bolt Hole)	030 027	Strut		030 028	Strut	
99-01	Chevrolet Malibu w/Late Design Rear Strut (2.50" Bolt Hole)	030 027	Strut		030 072	Strut	
2000-02	Chevrolet Tahoe w/Rear Nivomat				030 239	Nivomat	
2000-02	Chevrolet Tahoe XL w/Rear Nivomat				030 283	Nivomat	
Chrysler							
98-2000	Concorde, New Yorker/LHS					802 836	802 844
99-2000	Chrysler 300M					802 836	802 844
2000	Chrysler PT Cruiser	030 699	Strut				
97-2001	Chrysler Sebring Convertible					802 816	802 868
2001-02	Chrysler Minivan w/Rear Nivomat & AWD				030 284	Nivomat	
Dodge							
98-2000	Dodge Intrepid					802 836	802 844
2000	Dodge Neon	030 696	Strut		030 697 Lt.	Strut	
					030 698 Rt.	Strut	
Ford							
2000-02	Ford Focus Sedan	230 712 Lt.	Strut		230 714		802 845*
		230 711 Rt.	Strut		230 714		
2000-02	Ford Focus Wagon	230 712 Lt.	Strut		280 357		802 845*
		230 711 Rt.	Strut		280 357		
1998-00	Ford Contour, Mercury Mystic	030 060	Strut		030 061	Strut	802 772 802 775
1999	Ford Taurus (SHO) including Police Car						
	Left Side	030 065	Strut		030 066	Strut	
	Right Side	030 078	Strut		030 066	Strut	
2000-01	Ford Taurus (Exc. SHO & Wagon)	030 062 Lt.	Strut		030 064	Strut	
		030 063 Rt.	Strut		030 064	Strut	
GMC							
2000-02	GMC Suburban/Yukon w/Rear Nivomat				030 239	Nivomat	
2000-02	GMC Suburban/Yukon XL w/Rear Nivomat				030 283	Nivomat	
Honda							
98-02	Honda Accord	207 02A	Strut		207 07A	Strut	
94-97	Honda Accord	205 36A	Strut				
Hyundai							
1997-01	Hyundai Tiburon	030 067 Lt.	Strut		030 069 Lt.	Strut	802 869 802 870Lt.
		030 068 Rt.	Strut		030 070 Rt.	Strut	802 871Rt.
96-2000	Hyundai Elantra						802 869 802 870Lt. 802 871Rt.
Jaguar							
1994-97	Jaguar XJ-6 and XJ-12	230 108			230 110		

Year	Application	Shocks & Strut				Strut Mount	
		Front	Symbol	Rear	Symbol	Front	Rear
Jeep							
87-	Jeep X, XY Series w/Off Road Package	106 539	Strut	106 540	Strut		
99-00	Jeep Grand Cherokee (WJ)R	030 806		030 811			
Lexus							
96-97	Lexus GS300					802 846	
98-2000	Lexus GS300/GS400						
90-94	Lexus LS400 without Air Suspension					802 847	802 849
95-2000	Lexus LS400 without Air Suspension						802 848
92-96	Lexus ES300						802 851
92-99	Lexus SC300/SC400						802 852
95-96	Lexus ES300					802 854	
90-94	Lexus LS400	207 15A	Strut	207 19A	Strut		
95-2000	Lexus LS400	207 15A	Strut				
Mercedes Benz							
90-93	MB 300SL,500SL	36A 48A	Strut	36A 050			
95-99	MB SL320,SL500	36A 49A	Strut	36A 050			
1995-97	C36 AMG W202 (Chassis)	170 450		170 451			
1998-00	C43 AMG W202 (Chassis)	114 097		114 098			
1998-02	CLK320 Coupe (C208 Chassis)	553 821		553 713			
1999-02	CLK430 Coupe (C208 Chassis)	553 821		553 713			
1999-02	CLK320 Convertible (C208 Chassis)	553 821		553 717			
2001-02	C240 Sedan, C320 Sedan (C203 Chassis) w/Standard Suspension	553 993	Strut	553 870	Strut		
2001-02	C240 Sedan, C320 Sedan (C203 Chassis) w/Sport Suspension	553 871	Strut	553 870	Strut		
3/00-6/01	ML320/ML430 (W163 Chassis)			290 055	Strut		
Oldsmobile							
97-98	Oldsmobile Regency					802 861*	802 708
97-99	Oldsmobile Cutlass (Excluding Supreme)					802 866*	802 867
97-98	Oldsmobile Cutlass Supreme w/Early Design Rear Strut (3.25" Bolt Hole)	030 027	Strut	030 028	Strut		
99-01	Oldsmobile Cutlass Supreme w/Late Design Rear Strut (2.50" Bolt Hole)	030 027	Strut	030 072	Strut		
99-01	Oldsmobile Alero	030 027	Strut	030 072	Strut		
Pontiac							
99-2001	Pontiac Grand Am					802 866*	802 867
2000	Pontiac Bonneville						802 860
99-2001	Pontiac Sunfire					802 866*	802 805
Saab							
1999-02	9-3 (Exc. Sport Suspension & Convertible)	553 670	Strut	553 676			
1999-02	9-3 w/Sport Suspension (Exc. Convertible)	553 674	Strut	553 678			
1999-02	9-3 Convertible w/Standard Suspension	553 672	Strut	553 676			
1999-02	9-5 Sedan w/Standard Suspension	553 682	Strut	553 686			
1999-02	9-5 Sedan w/Sport Suspension	553 680	Strut	553 725			
2000-02	9-5 Station Wagon w/Standard Suspension	553 682	Strut	553 684			
2000-02	9-5 Station Wagon w/Sport Suspension	553 680	Strut	553 688			
Toyota							
96-2000	Toyota 4-Runner 4WD					802 850	
95-96	Toyota Avalon/Camry					802 854	
97-2001	Toyota Camry/Avalon Left Side Right Side					802 876*	802 877*
95-98	Toyota Tercel			205 37A	Strut		
99-2002	Toyota Solara	030 074 Lt.	Strut	030 076 Lt.	Strut		
		030 075 Rt.	Strut	030 077 Rt.	Strut		
Volvo							
2000-01	Volvo S40, V40	32E 74A Lt.	Strut	27D 13A			
2000-01	Volvo S40, V40		Strut	27D 13A			
1999-02	S80	554 046	Strut	554 044			
91-95	940 Sedan, Wagon w/Solid Rear Axle (Exc. 1991 SE w/IRS)	321 35F	Insert	271 82F			
				601 801	Nivomat		
1991	940SE w/IRS	321 35F	Insert	601 294	Nivomat		
92-94	960 Sedan, Wagon w/IRS (Nivomat marked w/H or M)	321 35F	Insert	271 82F			
				601 294	Nivomat		
92-94	960 Sedan, Wagon w/IRS (Nivomat marked w/5N or N)	321 35F	Insert	271 82F			
				601 800	Nivomat		
95-98	960 Sedan, S90 (Nivomat marked V or Z)			36A 30P			
				60A 920	Nivomat		
95-98	960 Wagon, V90 (Nivomat marked V or Z)			36-A31			
				60A 920	Nivomat		
95-98	960 Sedan, S90 (Nivomat marked U)			36A 30P			
				60A 910	Nivomat		
95-98	960 Wagon, V90 (Nivomat marked U)			36A 31P			
				60A 910	Nivomat		