

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
ACURA					
CL					
97-99	All	207 79A	207 88A	802 816	802 726
INTEGRA					
94-98	All	208 01A	208 02A	802 816	802 816
90-93	3 & 5Dr.	207 89A	207 90A	802 816	802 816
86-89	3 & 5Dr.	207 56A	205 04A		
LEGEND					
91-95	All				
	Left Side	208 63A	208 65A		
	Right Side	208 64A	208 65A		
87-90	Coupe	207 75A	207 74A	802 816	802 726
89-90	4Dr. Sedan	207 75A	207 74A	802 816	802 726
86-88	4Dr. Sedan	207 55A	207 09A		802 838
NSX					
91-99	All			802 816	802 816
RL					
96-00		TBA			
SLX					
96-99	4WD	206 55A	206 56A		
TL					
95-00		TBA			
VIGOR					
92-94	All	208 13A	208 12A	802 816	802 726
ALFA ROMEO					
81-87	Alfetta GTV-6	275 44B	254 45A		
75-80	Alfetta GTV, Sport Sedan	275 44B	275 45A		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model		Sachs <i>Super Gas</i>		Strut Mounts	
			Front	Rear	Front	Rear
ALFA ROMEO (Continued)						
ALFA ROMEO (Continued)						
5/85-92	Milano 2.5i, 3.0i	275 44B		275 45A		
70-81	Montreal	271 33H		271 34H		
90-94	164 V6 3.0i (Exc. Sport)	324 75B	✚	329 84A	✚	
9/65-80	1300, 1600, Berlina, Spider	271 33H		271 34H		
72-84	2000 Spider	271 33H		271 34H		
AMERICAN MOTORS						
ALLIANCE, ENCORE, GTA						
83-87	All	030 600	✚	030 714	802 812(*)	
AMBASSADOR, MATADOR, REBEL, MARLIN, CLASSIC						
70-78	All	030 802		030 273		
AMX, JAVELIN						
70-74	All	030 802		030 273		
78-80	AMX	030 704		030 803		
CONCORD, GREMLIN, HORNET, SPIRIT						
78-83	All	030 704		030 803		
71-77	All	030 802		030 804		
1970	All	030 802		030 805		
EAGLE						
80-88	All	030 705		030 273		
PACER						
75-80	All			030 271		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
AUDI					
A4					
98-00	Avant Wagon (1.8L & 2.8L) Left Side Right Side	330 86F	274 65F	↑ ↑	
			60A 090		
	60A 100				
96-00	Avant Wagon w/ Sport Suspension (1.8L & 2.8L) Quattro Sedan, Quattro Avant Wagon (1.8L & 2.8L)	330 87F 330 86F	324 23F	↑ ↑	
			274 46F		
	60A 090 60A 100				
96-00	Sedan (1.8L & 2.8L) Left Side Right Side	330 86F	274 46F	↑ ↑	
			60A 090		
	60A 100				
	Sedan w/ Sport Suspension (1.8L & 2.8L)	330 87F	274 46F		
A6					
97-00	Quattro, Quattro Avant Wagon (Exc. 2000 2.7L Turbo V6 & 4.2L V8)	330 86F	32D 15F		
	Quattro, Quattro Avant Wagon w/ Sport Suspension (Exc. 2000 2.7L Turbo V6 & 4.2L V8)	330 87F	32D 16F		
95-96	Quattro Sedan, Wagon	324 02F	325 05F		
97-00	Sedan, Wagon (Exc. Quattro & 2000 2.7L Turbo V6 & 4.2L V8)	330 86F	27C 11F 60A 060	↑	
	Sedan, Wagon w/ Sport Suspension (Exc. Quattro & 2000 2.7L Turbo V6 & 4.2L V8)	330 87F	27C 12F		
95-96	Sedan, Wagon (Exc. Quattro)	324 02F	326 92F		
CABRIOLET					
96-98	All	324 72F	272 05A		
94-95	All	324 72F	272 05A		802 830(*)
COUPE					
81-87	Coupe, GT	328 46F	270 93F 600 740	↑	802 830(*)
90-91	Coupe Quattro	324 72F	323 01F		
S4					
92-94	All	324 02F	321 15F		
S6					
1995	Quattro, Sedan	324 02F	321 15F		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
AUDI (Continued)					
V8					
90-94	V8 Quattro	324 02F	321 15F		
80/90					
95-96	All (Exc. Coupe Quattro)	324 72F			
88-96	All				802 830(*)
93-94	All (Exc. Coupe Quattro)	324 72F	278 10F		
91-92	Coupe (Exc. Coupe Quattro)	328 46F			
8/87-8/92	Coupe (Exc. Coupe Quattro)	328 46F	270 93F 601 520	↑	
93-96	Coupe Quattro (Incl. 20V)	324 72F			
8/91-8/92	Coupe Quattro (Incl. 20V)	328 46F	323 01F	↓	
11/88-7/91	Coupe Quattro (Incl. 20V)	328 46F	329 20F	↓	
90-91	90 Quattro (Exc. 20V)	324 72F	323 01F	↓	
	90 Quattro 20V	324 72F	321 15F		
100/200					
92-93	100 Sedan (Exc. Quattro)	324 02F	326 92F		
	100 Quattro Sedan	324 02F	325 05F		
2/88-91	100/200 (Exc. Quattro)	324 02F	328 59F 601 180	↑	
5/88-10/90	100/200 Quattro (Incl. Turbo)	324 02F	325 05F		
4000					
80-87	All				802 830(*)
9/86-7/87	4000 (Exc. Coupe, Quattro)	328 46F	270 93F 601 520	↑	
8/78-8/86	4000 (Exc. Coupe, Quattro)	328 46F	270 93F 600 740	↑	
11/83-7/87	4000 S, CS, Quattro	328 46F	329 20F	↓	
5000					
10/84-5/88	5000CS, Quattro Sedan	324 02F	325 05F		
9/83-1/88	5000S, Turbo, 5000 Wagon	324 02F	328 59F 601 180	↑	
10/84-5/88	5000 Quattro Wagon	324 02F			
6/77-9/83	5000 (Exc. Quattro)	324 02F	600 750	↑	

* Strut Mount and Bearing

** Bearing Only




























SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
BMW					
2500, 3.0, BAVARIA					
9/75-77	3.0 Si, SiA, Bavaria (E3)	329 39F			
4/71-8/75	2500, A, 3.0 S, SA, Si, SiA, Bavaria (E3)		106 802		
1600, 1800, 2002					
66-77	All (Incl. Tii) (E10)		779 032		
3 SERIES					
87-91	M3 (Grey Market Cars Only) (E30)	329 67F	279 74F		
83-10/91	318 (E30)				802 833
83-91	318i, 320i w/ Factory Sport Suspension (51 mm O.D. Strut Housing) (E30)	329 67F	279 74F		
10/82-85	318i w/ 45 mm O.D. Strut Housing (Exc. M Series) (E30)	270 79F	270 08F 600 820		
94-97	318ic Convertible w/ M-Technic (E36)				
	Left Side	366 41F	272 60F		
	Right Side	366 42F	272 60F		
	318ic Convertible w/ Standard Suspension (E36)				
	Left Side	366 13A	271 44C		802 833
	Right Side	366 14A	271 44C		802 833
6/92-99	318is Coupe, 4Dr. w/ M-Technic (Exc. 4Dr. in 1999) (E36)				
	Left Side	325 57FB	272 60F		
	Right Side	325 58FB	272 60F		
	318is Coupe, 4Dr. w/ Standard Suspension (Exc. 4Dr. in 1999) (E36)				
	Left Side	321 89A	271 44C		802 833
	Right Side	321 90A	271 44C		802 833
10/91-5/92	318is Coupe, 4Dr. w/ M-Technic (E36)				
	Left Side	329 61F	272 60F		
	Right Side	329 62F	272 60F		
	318is Coupe, 4Dr. w/ Standard Suspension (E36)				
	Left Side	328 75A	271 44C		802 833
	Right Side	328 76A	271 44C		802 833
89-92	318is, ic Convertible (E30)	327 20F	270 08F 600 820		

* Strut Mount and Bearing

** Bearing Only




























SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
BMW (Continued)					
3 SERIES (Continued)					
12/90-9/91	318is Coupe, 4Dr. w/ M-Technic (E36)				
	Left Side	322 27F		272 60F	
	Right Side	322 28F		272 60F	
	318is Coupe, 4Dr. w/ Standard Suspension (E36)				
	Left Side	320 39A		271 44C	802 833
	Right Side	320 40A		271 44C	802 833
95-97	318Ti w/ M-Technic (E36)				
	Left Side	325 57FB		273 04F	
	Right Side	325 58FB		273 04F	
95-99	318Ti w/ Standard Suspension (E36)				
	Left Side	321 89A		272 95B	802 833
	Right Side	321 90A		272 95B	802 833
9/76-10/82	320i (E21)	277 70F		270 43F	
8/77-10/82	320/6, 323i (European Model) (E21)	322 78F		270 43F	
83-86	323i (European Model) (E30)	327 20F		270 08F	
98-00	323ic Convertible w/ M-Technic (E36)				
	Left Side	366 41F			
	Right Side	366 42F			
	323ic Convertible w/ Standard Suspension (E36)				
	Left Side	366 13A		271 61B	802 833
	Right Side	366 14A		271 61B	802 833
	323is Coupe w/ M-Technic (E36)				
	Left Side	366 41F		272 60F	
	Right Side	366 42F		272 60F	
	323is Coupe w/ Standard Suspension (E36)				
	Left Side	330 13A		271 44C	802 833
	Right Side	330 14A		271 44C	802 833
10/82-91	325e, i (Exc. M Series) (E30)	327 20F		270 08F	802 833
2/95-96	325i w/ Standard Suspension (E36)				
	Left Side	330 13A		271 44C	
	Right Side	330 14A		271 44C	
6/92-95	325i w/ M-Technic (E36)				
	Left Side	366 41F		272 60F	
	Right Side	366 42F		272 60F	
6/92-1/95	325i w/ Standard Suspension (E36)				
	Left Side	366 13A		271 44C	802 833
	Right Side	366 14A		271 44C	802 833
86-93	325i Convertible (E30)	100 857		105 762	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
BMW (Continued)					
3 SERIES (Continued)					
10/91-5/92	325i w/ M-Technic (E36)				
	Left Side	366 81F		272 60F	
	Right Side	366 82F		272 60F	
	325i w/ Standard Suspension (E36)				
	Left Side	366 21A		271 44C	802 833
	Right Side	366 22A		271 44C	802 833
12/90-9/91	325i w/ M-Technic (E36)				
	Left Side	367 71F		272 60F	
	Right Side	367 72F		272 60F	
	325i w/ Standard Suspension (E36)				
	Left Side	367 69A		271 44C	802 833
	Right Side	367 70A		271 44C	802 833
2/95-96	325ic Convertible w/ Standard Suspension (E36)				
	Left Side	366 13A		271 44C	
	Right Side	366 14A		271 44C	
94-95	325ic Convertible w/ M-Technic (E36)				
	Left Side	366 41F			
	Right Side	366 42F			
94-1/95	325ic Convertible w/ Standard Suspension (E36)				
	Left Side	366 13A		271 44C	
	Right Side	366 14A		271 44C	
8/85-91	325ix w/ Sport Suspension (E30)			270 08F	
	325ix w/ Standard Suspension (E30)	323 83A		270 08F	
96-00	328i w/ M-Technic (E36)				
	Left Side	366 41F		272 60F	
	Right Side	366 42F		272 60F	
	328i w/ Standard Suspension (E36)				
	Left Side	330 13A		271 44C	802 833
		Right Side	330 14A		271 44C
	328ic Convertible w/ M-Technic (E36)				
	Left Side	366 41F			
	Right Side	366 42F			
	328ic Convertible w/ Standard Suspension (E36)				
	Left Side	366 13A		271 61B	
		Right Side	366 14A		271 61B
328is Coupe w/ M-Technic (E36)					
Left Side	366 41F		272 60F		
Right Side	366 42F		272 60F		
328is Coupe w/ Standard Suspension (E36)					
Left Side	330 13A		271 44C	802 833	
Right Side	330 14A		271 44C	802 833	

Note: E21 (9/76-8/79) use locking ring "0376", (9/79-10/82) use locking ring "0353"

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
BMW (Continued)					
5 SERIES					
86-2/87	M5 (E28) Left Side Right Side			102 149 102 150	
8/90-12/95	518i, 520i M50 w/ Std. Suspension w/o EDC (E34)	320 58A		326 50F 601 550	
88-7/90	518i, 520i M50 w/ Std. Suspension w/o EDC (E34)	329 79A		326 50F 601 550	
3/83-3/86	524td (E28)			328 33F	
92-95	525iT, 530iT w/ Std. Suspension w/o EDC (E34) Left Side Right Side	367 47A		326 50F 102 283 102 284	
1/88-95	525i, 530i, 535i w/ EDC (E34) Left Side Right Side	100 812		112 235 102 209 102 210	
93-95	525i, 535i w/ Std. Suspension w/o EDC (E34) Left Side Right Side	320 58A		326 50F 102 209 102 210	
7/90-92	525i, 535i w/ Std. Suspension w/o EDC (E34) Left Side Right Side	367 47A		326 50F 102 209 102 210	
1/88-6/90	525i, 535i w/ Std. Suspension w/o EDC (E34) Left Side Right Side	366 76F		326 50F 102 209 102 210	
8/76-5/81	528, A, 528i, 530i, A (E12)	329 39F		320 53F 600 660	
6/81-1/88	528e, 533i, 535i, is (E28) Left Side Right Side	328 39F		322 79F 102 803 102 804	
95-00	528i w/ M-Technic (E39)	36A 61A		330 35A	
	528i w/ Standard Suspension (E39)	36A 60A		330 56A	
94-95	530i, 540i w/ Std. Suspension w/o EDC (E34) Left Side Right Side	367 47A		326 50F 102 209 102 210	
75-7/76	530i, A (E12)			600 660	
95-00	540i, iA w/ M-Technic (E39)	36A 63A		330 35A	
	540i, iA w/ Standard Suspension (E39)	36A 62A		330 56A	
6 SERIES					
87-90	M6 (E24) Left Side Right Side			102 149 102 150	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts		
		Front	Rear	Front	Rear	
BMW (Continued)						
6 SERIES (Continued)						
7/78-6/82	630 CSi, 633 CSi (E24)	329 39F		320 53F		
76-6/78	630 CSi, 633 CSi (E24)			320 53F		
9/82-9/84	633 CSi (E24)	328 39F		322 79F		
	Left Side			102 163		
	Right Side			102 164		
9/82-90	635 CSi (E24)	328 39F		322 79F		
	Left Side			102 163		
	Right Side			102 164		
7 SERIES						
10/81-8/86	733i, 735i (E23)	322 08A		322 06A		
	Left Side			102 800		
	Right Side			102 801		
9/79-9/81	733i, 735i (E23)	322 08A		102 802		
77-8/79	733i, 735i (E23)	322 08A				
8/90-92	735i, iL w/ Standard Suspension w/o EDC (E32)	367 46A		324 68A		
	Left Side			102 234		
	Right Side			102 235		
3/88-7/90	735i, iL w/ Standard Suspension w/ EDC (E32)	100 863		324 68A		
	Left Side			102 815		
	Right Side			102 816		
		735i, iL w/ Standard Suspension w/o EDC (E32)	366 79A		324 68A	
	Left Side	102 222				
	Right Side	102 223				
9/86-9/87	735i, iL w/ Standard Suspension w/o EDC (E32)	366 40A		324 68A		
94-00	740i, iA, iL w/ Standard Suspension w/ EDC (E38)					
	Left Side	115 440		102 817		
	Right Side	115 441		102 818		
		740i, iA, iL w/ Standard Suspension w/o EDC (E38)				
	Left Side	376 05A		323 30A		
	Right Side	376 06A		323 30A		
93-94	740i, iL w/ Standard Suspension w/o EDC (E32)	367 46A		324 68A		
9/81-9/86	745i (E23)					
	Left Side	322 08A		102 800		
	Right Side	322 08A		102 801		
4/80-9/86	745i Turbo (E23)					
	Left Side	322 08A		102 800		
	Right Side	322 08A		102 801		
80-81	745i (E23)	322 08A		102 802		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear

BMW (Continued)

7 SERIES (Continued)

94-00	750i, iL w/o EDC (E38)	Left Side	376 05A	🔧		
	Right Side	376 06A	🔧			
	750i, iL w/ EDC (E38)	Left Side			102 817	🔧
		Right Side			102 818	🔧
8/90-94	750i, iL w/ Standard Suspension w/o EDC (E32)	Left Side	367 46A	🔧	102 234	🔧
		Right Side	367 46A	🔧	102 235	🔧
9/87-7/90	750i, iL w/ Standard Suspension w/o EDC (E32)	Left Side	366 79A	🔧	102 234	🔧
		Right Side	366 79A	🔧	102 235	🔧

Z3

95-98	1.9L Engine	Left Side	32C 02F	🔧	27B 56F	
	Right Side	32C 01F	🔧	27B 56F	802 833	
96-00	2.8L Engine	Left Side	32C 02F	🔧	27B 56F	802 833
		Right Side	32C 01F	🔧	27B 56F	802 833

BUICK

APOLLO, SKYLARK, SPECIAL

84-85	All				802 704
74-79	All	030 226	🔧	030 227	
1973	All (Exc. HD Suspension)	030 226	🔧	030 227	
	All w/ HD Suspension	030 226	🔧	030 227	
68-72	All (Exc. 68-69 Sportwagon)	030 226	🔧	030 227	
1985	Skylark	030 003	🔧	030 240	
1984	Skylark (Exc. HD Suspension)	030 010	🔧	030 240	
	Skylark w/ HD Suspension	030 003	🔧	030 240	
82-83	Skylark		🔧		802 735(*)
80-83	Skylark	030 010	🔧	030 240	

CENTURY

97-00	All	208 61A	🔧	208 62A	🔧
90-96	All		🔧		802 735(*)
85-96	All	030 003	🔧	030 240	802 704

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
BUICK (Continued)					
CENTURY (Continued)					
1984	All w/ HD Suspension	030 003	⚙️ 030 240		802 704
	All (Exc. HD Suspension)	030 010	⚙️ 030 240		802 704
82-83	All	030 010	⚙️ 030 227		802 704
73-81	All	030 226	030 227		
FULL SIZE					
71-84	All (Exc. Station Wagon)	030 229	030 227		
91-99	LeSabre w/ Optional OE Self-Leveling System	030 682	⚙️ 030 687	⚙️	
	LeSabre w/ Standard Rear Suspension	030 682	⚙️ 030 679	⚙️	
90-96	LeSabre				802 719(**)
90-95	LeSabre				802 738(*)
86-95	LeSabre				802 708
87-90	LeSabre (1st Design Only)				802 719(**)
86-90	LeSabre w/ Optional OE Self-Leveling System	030 676	⚙️ 030 687	⚙️	
	LeSabre w/ Standard Rear Suspension	030 676	⚙️ 030 679	⚙️	
86-89	LeSabre				802 737(*)
1985	LeSabre	030 229	030 227		
91-96	Park Avenue				802 719(**)
	Park Avenue/Electra Air Assist Rear Susp. (Std. Eq.)	030 682	⚙️ 030 687	⚙️	802 738(*)
	Park Avenue/Electra Conventional Type	030 682	⚙️ 030 679	⚙️	802 738(*)
87-96	Park Avenue				802 708
87-90	Park Avenue				802 719(**)
	Park Avenue/Electra				802 737(*)
85-90	Park Avenue/Electra Air Assist Rear Susp. (Std. Eq.)	030 676	⚙️ 030 687	⚙️	
	Park Avenue/Electra Conventional Type	030 676	⚙️ 030 679	⚙️	
85-86	Park Avenue/Electra				802 737(*) 802 708
92-96	Roadmaster Sedan	030 229	030 227		
77-96	Station Wagon (RWD)	030 229	030 227		
71-76	Station Wagon	030 229	030 227		
1970	Station Wagon	030 807	030 227		
REATTA					
90-93	All				802 719(**)
	All				802 756(*) 802 778
88-91	All	030 681	⚙️		
88-89	All				802 757(*) 802 778
REGAL					
97-00	All	208 61A	⚙️ 208 62A	⚙️	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
BUICK (Continued)					
REGAL (Continued)					
90-96	All w/ HD Suspension				802 824(*)
	All (Exc. HD Suspension)				802 823(*)
88-96	All	030 001	030 680		802 707(*)
88-89	All (Exc. HD Suspension)				802 822(*)
	All w/ HD Suspension				802 825(*)
73-87	All	030 226	030 227		
RIVIERA					
95-97	All				802 803(*) 802 704
90-97	All				802 719(**)
95-96	All	030 682	030 980(***)		
90-93	All	030 681	030 678		802 756(*) 802 778
86-89	All	030 677	030 678		802 757(*) 802 778
79-85	All	030 702	030 981(***)		
71-78	All	030 229	030 227		
SKYHAWK					
84-89	All				
	Left Side	030 008	030 231		
	Right Side	030 009	030 231		
82-89	All				802 706(*) 802 704
84-86	All	030 741	030 231		
82-83	All	030 736	030 231		
75-80	All	030 808	030 703		
SKYLARK					
96-98	All				
	Left Side	030 692	030 732		802 779(*) 802 704
	Right Side	030 693	030 732		802 779(*) 802 704
92-98	All				802 719(**)
1995	All (Exc. Electronic Suspension)				
	Left Side	030 683	030 231		802 779(*) 802 704
	Right Side	030 684	030 231		802 779(*) 802 704
92-94	All (Exc. FE3 & Electronic Suspension)				
	Left Side	030 683	030 231		802 736(*) 802 704
	Right Side	030 684	030 231		802 736(*) 802 704
92-93	All w/ FE3 Suspension				
	Left Side	030 685	030 231		802 736(*) 802 704
	Right Side	030 686	030 231		802 736(*) 802 704

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
BUICK (Continued)					
SOMERSET					
85-91	All w/ Non-Rebuildable OE Struts				
	Left Side	030 008	030 231	802 706(*)	802 704
	Right Side	030 009	030 231	802 706(*)	802 704
SOMERSET REGAL					
92-94	All (Exc. Elec. Suspension)			802 736(*)	
85-91	All w/ Non-Rebuildable OE Struts				
	Left Side	030 008	030 231	802 706(*)	802 704
	Right Side	030 009	030 231	802 706(*)	802 704
CADILLAC					
ALLANTE					
87-93	All			802 756(*)	802 778
	All			802 719(**)	
89-90	All (Exc. Elec. Adj. Suspension)	030 681	030 678	802 756(*)	802 778
87-88	All (Exc. Elec. Adj. Suspension)	030 677	030 678		
CALAIS, DEVILLE, FLEETWOOD					
77-90	All (RWD)	030 229	030 227		
71-76	All	030 807	030 809		
87-97	DeVille (FWD)			802 719(**)	
91-93	DeVille & Fleetwood (FWD)			802 738(*)	
	DeVille & Fleetwood (FWD)				
	Air Assist Rear Suspension (Std. Equipment)	030 682	030 687		
	Conventional Type - Repl. for Air Assist Rear Susp.	030 682	030 679		
85-93	DeVille & Fleetwood (FWD)				802 708
85-90	DeVille & Fleetwood (FWD)				
	Air Assist Rear Suspension (Std. Equipment)	030 676	030 687	802 737(*)	
	Conventional Type - Repl. for Air Assist Rear Susp.	030 676	030 679	802 737(*)	
87-93	Fleetwood (FWD)			802 719(**)	
CATERA					
97-00		TBA			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
CADILLAC (Continued)					
CIMARRON					
84-89	All				
	Left Side	030 008	030 231		
	Right Side	030 009	030 231		
82-88	All			802 706(*)	802 704
82-83	All	030 736	030 231		
COMMERCIAL CHASSIS					
77-85	All	030 229	030 227		
68-76	All	030 807	030 804		
ELDORADO					
93-98	All			802 719(**)	
87-94	All			802 756(*)	
87-92	All				802 778
1990	All	030 681	030 678		
86-89	All	030 677	030 678		
79-85	All	030 702	030 981(***)		
71-78	All	030 810	030 982(***)		
ESCALADE					
99-00		TBA			
SEVILLE					
98-99	All			802 704	
93-97	All			802 719(**)	
87-92	All			802 756(*)	
86-92	All				802 778
1990	All	030 681	030 678		
86-89	All	030 677	030 678		
80-85	All	030 702	030 981(***)		
75-79	All	030 226	030 983(***)		
CHEVROLET					
ASTRO VAN					
85-89	All	030 204	030 214		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
CHEVROLET (Continued)					
ASTRO VAN (Continued)					
90-00	2WD	030 204	030 214		
	4WD	030 221	030 214		
BERETTA					
1996	All				
	Left Side	030 692	030 732	802 779(*)	802 704
	Right Side	030 693	030 732	802 779(*)	802 704
92-96	All			802 719(**)	
1995	All				
	Left Side	030 683	030 732	802 779(*)	802 704
	Right Side	030 684	030 732	802 779(*)	802 704
92-94	All (Exc. GT, FE7 Suspension)				
	Left Side	030 683	030 231	802 736(*)	802 704
	Right Side	030 684	030 231	802 736(*)	802 704
92-93	GT, FE7 Suspension				
	Left Side	030 685	030 231	802 736(*)	802 704
	Right Side	030 686	030 231	802 736(*)	802 704
87-91	All				
	Left Side	030 008	030 231	802 717(*)	802 704
	Right Side	030 009	030 231	802 717(*)	802 704
BLAZER					
83-99	2WD S-10	030 209	030 210		
73-84	2WD	030 223	030 201		
69-72	2WD w/ Rear Coil Springs	030 223	030 836		
	2WD w/ Rear Leaf Springs	030 223	030 242		
83-99	4WD S-10	030 211	030 210		
92-94	4WD K-1500	030 221	030 780		
81-91	4WD Quad Suspension (Exc. S-10 & Lift Kit)				
	Long Shock Front (2 reqd.)	030 207	030 201		
	Short Shock Front (2 reqd.)	030 200	030 201		
73-91	4WD (Exc. Quad Suspension, S-10 & Lift Kit)	030 200	030 201		
73-90	4WD w/ 4" Lift Kit (Exc. Quad Suspension & S-10)	030 757	030 758		
71-72	4WD	030 200	030 754		
69-70	4WD	030 200			
C & R SERIES					
73-86	C-10	030 223	030 201		
67-72	C-10 w/ Rear Coil Springs	030 223	030 837		
	C-10 w/ Rear Leaf Springs	030 223	030 242		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
CHEVROLET (Continued)					
C & R SERIES (Continued)					
73-86	C-20 (Exc. Crew Cab & Bonus Cab)	030 223	030 201		
	C-20 Crew Cab & Bonus Cab	030 223	030 246		
67-72	C-20 w/ Rear Coil Springs	030 223	030 837		
	C-20 w/ Rear Leaf Springs	030 223	030 836		
85-86	C-30	030 223	030 246		
73-84	C-30	030 223	030 246		
67-72	C-30 (Exc. 11,000 lb Rear Axle)	030 223	030 242		
	C-30 w/ 11,000 lb Rear Axle	030 223			
99-00	C-1500 w/ New Body Style	030 846	030 782		
92-00	C-1500, C-2500 Suburban	030 217	030 780		
88-99	C-1500 Pickup	030 217	030 216		
	C-2500, C-3500 Pickup (Exc. C-3500 Crew Cab & HD w/ Straight Front Axle)	030 217	030 216		
96-00	C-3500 HD w/ Solid Front Axle	030 855	030 216		
87-88	R-10 & R-20 Pickup & Suburban (Exc. Crew Cab & Bonus Cab Pickups)	030 223	030 201		
	R-20 Crew Cab & Bonus Cab Pickup	030 223	030 246		
	R-30 Pickup & Cab/Chassis Models	030 223	030 246		
89-91	R-1500 Suburban	030 223	030 201		
	R-2500 Suburban	030 223	030 201		
89-90	R-2500 Pickup Crew Cab	030 223	030 246		
	R-3500 Pickup Crew Cab & Cab/Chassis Models	030 223	030 246		
CAMARO					
93-00	All				
	Left Side	030 750	030 230	802 801	
	Right Side	030 750	030 230	802 802	
82-92	All (Exc. 1987 w/ HD/Touring Suspension)				
	Left Side	030 675	030 230	802 715(*)	
	Right Side	030 675	030 230	802 716(*)	
70-81	All	030 229	030 700		
CAVALIER					
95-00	All	030 646	030 688	802 779(*) 802 719(**)	802 805
92-94	All			802 717(*)	802 704
87-94	All				
	Left Side	030 008	030 231		
	Right Side	030 009	030 231		
82-91	All			802 706(*)	802 704

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
CHEVROLET (Continued)					
CAVALIER (Continued)					
84-86	All w/ Non-Rebuildable OE Struts				
	Left Side	030 008	030 231		
	Right Side	030 009	030 231		
82-83	All	030 736	030 231		
CELEBRITY					
85-90	All	030 003	030 240	802 735(*)	
84-90	All				802 704
1984	All (Exc. HD Suspension)	030 010	030 240		
	All w/ HD Suspension	030 003	030 240		
82-83	All	030 010	030 240	802 735(*)	
CHEVELLE, MALIBU					
68-83	All	030 226	030 227		
CHEVETTE					
76-87	All	030 272	030 273		
CHEVY II					
85-88	All (Exc. Twin Cam)	030 653	030 658	802 710(*)	802 748
74-79	All	030 226	030 821		
1973	All (Incl. HD Suspension)	030 226	030 821		
68-72	All w/ Single & Multi-Leaf Rear Springs	030 226	030 821		
CITATION					
1985	All	030 003	030 240		
84-85	All				802 704
1984	X-11 & HD Suspension	030 003	030 240		
80-84	All (Exc. X-11 & HD Suspension)	030 010	030 240		
82-83	All			802 735(*)	
CORSICA					
95-96	All				
	Left Side	030 683	030 732	802 779(*)	802 704
	Right Side	030 684	030 732	802 779(*)	802 704
92-96	All			802 719(**)	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
CHEVROLET (Continued)					
CORSICA (Continued)					
92-94	All (Exc. FE7 Suspension)				
	Left Side	030 683	030 231	802 735(*)	802 704
	Right Side	030 684	030 231	802 735(*)	802 704
92-93	All w/ FE7 Suspension				
	Left Side	030 685	030 231	802 735(*)	802 704
	Right Side	030 686	030 231	802 735(*)	802 704
87-91	All				
	Left Side	030 008	030 231	802 717(*)	802 704
	Right Side	030 009	030 231	802 717(*)	802 704
CORVETTE					
97-00	All w/ 36 mm (Exc. Elect. Adj. Susp.)	030 276	030 277		
	All w/ 45 mm Sport Suspension (Exc. Elec. Adj. Suspension)	030 278	030 279		
89-96	All (Exc. Elect. Adj. Suspension)	030 727	030 726		
1988	All	030 725	030 726		
84-87	All	030 723	030 722		
63-82	All	030 267	030 720		
EL CAMINO					
68-87	All	030 209	030 227		
FULL SIZE					
71-96	Police, Taxi	030 204	030 227		
	All (Incl. Station Wagon, exc. Police & Taxi)	030 229	030 227		
G SERIES, CHEVY VAN & SPORTVAN					
96-00	G-10 & G-20 Express Van (Exc. G-20 8600 lb GVW)	030 204	030 780		
78-95	G-10 & G-20 (Exc. G-20 8600 lb GVW)	030 202	030 207		
71-77	G-10, G-20, G-30 (Exc. G-30 w/ 146" Wheelbase)	030 202	030 242		
1970	G-10 w/ Independent Front Suspension	030 202	030 242		
	G-10, G-20 w/ I-Beam Front Axle		030 242		
	G-20 w/ Independent Front Suspension	030 202	030 242		
97-00	G-30 Express Van	030 204	030 780		
92-96	G-30 w/ 7100 lb w/ Chassis Cab, 7400 lb, 8600 lb GVW	030 202	030 783		
79-96	G-30 w/ 9200 lb GVW	030 202	030 767		
78-96	G-30 (Exc. 7100 lb w/ Chassis Cab, 7400 lb, 8600 lb & 9200 lb GVW)	030 202	030 207		
75-77	G-30 w/ 146" Wheelbase	030 202			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
CHEVROLET (Continued)					
IMPALA					
2000		TBA			
K & V SERIES 4WD PICKUP & SUBURBAN					
81-86	K-10 & K-20 Quad Suspension (Exc. Lift Kit) Long Shock Front (2 reqd.) Short Shock Front (2 reqd.)	030 207 030 200	030 201 030 201		
73-86	K-10, K-20 w/ 4" Lift Kit (Exc. Quad Suspension)	030 757	030 758		
	K-10 & K-20 (Exc. Quad Suspension & Lift Kit)	030 200	030 201		
71-72	K-10 & K-20	030 200	030 754		
69-70	K-10 & K-20	030 200			
99-00	K-1500 w/ New Body Style	030 856	030 756		
88-99	K-1500 (Incl. Z-71)	030 857	030 216		
92-00	K-1500, K-2500 Suburban	030 221	030 780		
88-99	K-2500, K-3500 Pickup	030 221	030 216		
87-88	V-10, V-20 w/ 4" Lift Kit Shocks Mounted Behind Front Axle (Exc. Quad Suspension)	030 757	030 758		
	V-10 & V-20 (Exc. Quad Suspension & Lift Kit)	030 200	030 201		
	V-10 & V-20 Quad Suspension (Exc. Lift Kit) Long Shock Front (2 reqd.) Short Shock Front (2 reqd.)	030 207 030 200	030 201 030 201		
	V-30	030 768	030 756		
	89-91	V-1500 Suburban (Exc. Quad Suspension & Lift Kit) Long Shock Front (2 reqd.) Short Shock Front (2 reqd.)	030 200 030 207 030 200	030 201 030 201 030 201	
89-91	V-1500, V-2500 Suburban w/ 4" Lift Kit Shocks Mounted behind Front Axle (Exc. Quad Susp.)	030 757	030 758		
	V-2500 Suburban (Exc. Quad Suspension & Lift Kit)	030 200	030 201		
	V-2500 Suburban w/ Quad Suspension (Exc. Lift Kit) Long Shock Front (2 reqd.) Short Shock Front (2 reqd.)	030 207 030 200	030 201 030 201		
	V-3500 Pickup Crew Cab & Cab/Chassis	030 768	030 756		
LUMINA					
95-99	All	030 001	030 666		
90-99	All (Exc. HD Suspension)			802 823(*)	
	All w/ HD Suspension			802 824(*)	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
CHEVROLET (Continued)					
LUMINA (Continued)					
90-96	All				802 707(*)
	APV Van	030 003	030 799	802 735(*)	802 704
89-94	All	030 001	030 680		
LUV, PICKUP					
81-82	2WD	030 236	030 262		
	4WD	030 706	030 262		
79-80	2 & 4WD	030 706	030 222		
MALIBU					
97-00		TBA			
METRO					
98-00		TBA			
MONTE CARLO					
95-99	All w/ HD Suspension			802 824(*)	
	All (Exc. HD Suspension)			802 823(*)	
	All	030 001	030 666		802 800
70-88	All	030 226	030 227		
MONZA					
75-80	All		030 703		
NOVA					
85-88	All (Exc. Twin Cam)	030 653	030 658	802 710(*)	802 748
74-79	All	030 226	030 821		
1973	All (Incl. HD Suspension)	030 226	030 821		
68-72	All w/ Single & Multi-Leaf Rear Springs	030 226	030 821		
PRIZM					
98-00	All				
	Left Side	030 631	030 633		
	Right Side	030 632	030 634		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
CHEVROLET (Continued)					
P SERIES STEP-VAN					
74-80	P-10	030 223	030 246		
1973	P-10	030 223	030 201		
67-72	P-10	030 223	030 242		
79-90	P-20	030 223	030 246		
73-78	P-20	030 223	030 201		
68-72	P-20 & P-30 (Exc. 11,000 lb Rear Axle)	030 223	030 242		
86-99	P-30 Motorhome Chassis w/ I-Beam Front Susp.	030 778	030 246		
85-99	P-30 Motorhome Chassis w/ Independent Front Suspension	030 250	030 246		
73-90	P-30 (Exc. Motorhome Chassis)	030 223	030 246		
1985	P-30 Motorhome Chassis w/ I-Beam Front Susp.	030 767	030 246		
74-84	P-30 Motorhome Chassis	030 250	030 246		
68-72	P-30 w/ 11,000 lb Rear Axle	030 223			
S SERIES PICKUP					
82-99	S-10 2WD (Exc. Sport Chassis)	030 209	030 210		
83-99	S-10 4WD	030 211	030 210		
SPRINT					
89-91	All	030 662	030 660	802 752	802 754
87-88	All	030 657	030 710		
85-88	All			802 835	
85-86	All	030 657	030 708		
TAHOE					
95-00	C-1500 2WD	030 217	030 780		
	K-1500 4WD	030 221	030 780		
TRACKER					
98-00	All				
	Left Side	030 628	030 858	802 753	
	Right Side	030 629	030 858	802 753	
VEGA					
72-77	All	030 808	030 703		
1971	All	030 808			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
CHEVROLET (Continued)					
VENTURE					
97-00	All	208 61A	030 850		
CHRYSLER					
CIRRUS					
2000	All (w/o Bracket)	030 667	030 747	802 816	802 771
95-99	All	030 667	030 747	802 816	802 771
CONCORDE (LH)					
98-00	All				
	Left Side	030 635	030 694	802 836	
	Right Side	030 636	030 694	802 836	
93-97	All				
	Left Side	030 635	030 637	802 730(*)	802 751
	Right Side	030 636	030 637	802 730(*)	802 751
CORDOBA					
80-83	All	030 235	030 268		
77-79	All	030 701	030 268		
75-76	All	030 701	030 812		
E-CLASS (E BODY)					
1984	All	030 015	030 228	801 702(*)	
1983	All	030 011	030 228	802 701(*)	
EXECUTIVE					
1989	Limousine		030 228		
86-88	Limousine (Mfg. after Jan/86)	030 005	030 228	802 703(*)	
85-86	Limousine (Mfg. to Jan/86)			802 702(*)	
84-86	Limousine (Mfg. to Jan/86)	030 015	030 228		
84-85	Sedan			802 702(*)	
1983	Sedan	030 011	030 228	802 701(*)	
FULL SIZE					
79-81	All	030 701			
70-73	All (Exc. 1970 Station Wagon)	030 813			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
CHRYSLER (Continued)					
FULL SIZE (Continued)					
1970	Station Wagon	030 813	030 812		
IMPERIAL (Y BODY)					
90-93	All (Exc. Self Leveling System)			802 703(*)	
81-83	All (M Body)	030 235	030 268		
67-73	All	030 813			
74-75	All (M Body)	030 235	030 812		
88-93	5th Avenue, Imperial (Exc. Self Leveling System)	030 005	030 228	802 703(*)	
LASER (G BODY)					
1986	All (Mfg. after Jan/86)	030 005	030 228	802 703(*)	
84-86	All (Mfg. to Jan/86)	030 015	030 228	802 702(*)	
LEBARON (J BODY)					
86-95	All A Body Sedan, H Body GTS, J Body Coupe (Mfg. after Jan/86)	030 005	030 228	802 703(*)	
84-86	All K Body, H Body GTS (Mfg. to Jan/86)	030 015	030 228		
1983	All			802 701(*)	
82-83	All	030 011	030 228		
81-82	All			802 700(*)	
77-81	All M Body	030 235	030 268		
NEW YORKER (C BODY) FWD					
88-93	New Yorker, Salon, Landau (Exc. Self Level. Sys.)	030 005	030 228	802 703(*)	
NEW YORKER (E BODY)					
86-88	New Yorker (FWD) (Mfg. after Jan/86)	030 005	030 228	802 703(*)	
84-86	New Yorker (Incl. Turbo, mfg. to Jan/86)	030 015	030 228	802 702(*)	
1983	New Yorker (FWD)	030 011	030 228	802 701(*)	
NEW YORKER (M BODY)					
82-89	New Yorker, Fifth Avenue (RWD)	030 235	030 268		
79-81	All Full Size		030 268		
74-78	All Full Size	030 235	030 812		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear

CHRYSLER (Continued)

NEW YORKER, LHS (LH BODY)

98-00	All				
	Left Side	030 635	030 694		
	Right Side	030 636	030 694		
94-97	All				
	Left Side	030 635	030 637	802 730(*)	802 751
	Right Side	030 636	030 637	802 730(*)	802 751

PT CRUISER

2000		TBA			
------	--	-----	--	--	--

SEBRING

96-00	All (Exc. Convertible)	030 669	030 748	802 806	802 806
	Convertible Only	030 667	030 747		802 771

TOWN & COUNTRY (K BODY)

86-88	Station Wagon	030 005	030 228		
-------	---------------	---------	---------	--	--

TOWN & COUNTRY VAN (S BODY)

96-00	All w/ Self Leveling System	030 645	030 051	802 770	
	All (Exc. Self Leveling System)	030 645	030 791	802 770	
90-95	All	030 004	030 213	802 703(*)	

300M

99-00	All				
	Left Side	030 635	030 694		
	Right Side	030 636	030 694		

DODGE

A & B SERIES LIGHT DUTY VAN & SPORTSMAN WAGON

70-80	B-100, B-200, B300 (Exc. B-300 w/ 4000 lb Front Axle)	030 203	030 207		
81-00	B-150, B-250, B350 (Exc. B-350 w/ 4000 lb Front Axle) & R150 w/ 127" Wheelbase & 7000 lb GVW	030 203	030 207		
70-80	B-300 w/ 4000 lb Front Axle	030 245	030 207		
81-90	B-350 w/ 4000 lb Front Axle	030 245	030 207		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
DODGE (Continued)					
ARIES (K BODY)					
86-89	All (Mfg. after Jan/86)	030 005	⚙️ 030 228	802 703(*)	
84-86	All (Mfg. to Jan/86)	030 015	⚙️ 030 228	802 702(*)	
1983	All			802 701(*)	
81-83	All	030 011	⚙️ 030 228		
81-82	All			802 700(*)	
ASPEN					
76-80	All	030 235	030 268		
AVENGER					
95-00	All	030 669	⚙️ 030 748	802 806	802 806
CB & MB SERIES - COMPACT FRONT SECTION					
78-80	CB-300, MB-300 (Exc. w/ 4000 lb Front Axle)	030 203	030 207		
	CB-300, MB-300 w/ 4000 lb Front Axle	030 245	030 207		
70-77	CB-300, MB-300 w/ GVW over 8300 lb	030 245	030 207		
	CB-300, MB-300 w/ GVW up to 8300 lb	030 203	030 207		
78-80	CB-400, MB-400	030 245	030 207		
81-93	MB-300, 350, BF-300, 350 w/ 4000 lb Front Axle	030 245	030 207		
	MB-300, 350, BF-300, 350 (Exc. w/ 4000 lb Front Axle)	030 203	030 207		
CARAVAN (S BODY)					
96-00	All w/ Self Leveling	030 645	⚙️ 030 051	⬆️	
	All (Exc. Self Leveling)	030 645	⚙️ 030 791	802 770	
86-95	All (Mfg. after Jan/86, incl. AWD)	030 004	⚙️ 030 213	802 703(*)	
84-86	All (Mfg. to Jan/86)	030 601	⚙️ 030 213	802 702(*)	
CHALLENGER					
81-83	All	030 735	⚙️	802 761	
78-80	All	030 735	⚙️		
70-74	All	030 816	030 812		
CHARGER, CORONET, MAGNUM XE					
73-79	All	030 701	030 812		
65-72	All		030 812		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear

DODGE (Continued)

COLT

93-95	All				
	Left Side	030 672	030 746	802 767(*)	802 806
	Right Side	030 672	030 746	802 767(*)	802 806
85-86	All (Exc. Vista Station Wagon)	030 654	030 274		
71-76	All (Exc. Station Wagon)	030 735			
1977	Carrousel & GT 2Dr. Hardtop	030 735			
87-88	Colt-E 3Dr.	030 612	030 274		
77-79	Coupe & 4Dr. Sedan	030 735	030 818		
89-92	Hatchback, GL	030 616	030 743	802 745	802 806
79-84	Hatchback (Exc. Models w/ Sealed Front Struts)	030 734	030 274	802 749(*)	
88-89	Station Wagon 2 & 4WD	030 612	030 730		
78-80	Station Wagon	030 735	030 274		
71-77	Station Wagon	030 735	030 719		
85-91	Vista Station Wagon 4WD	030 609	030 715	802 808	
84-91	Vista Station Wagon 2WD	030 607	030 274	802 808	

CONQUEST

87-89	All (Exc. Elec. Adj. Susp.)	030 737	030 606	802 766(*)	802 765
84-86	All (Exc. ESI)	030 738	030 606	802 766(*)	802 765

D SERIES 2WD PICKUP

85-93	D-100	030 203	030 244		
72-80	D-100, D-150	030 203	030 244		
81-93	D-150	030 203	030 244		
90-93	D-200, D-250 (Exc. Heavy Duty Package, Crew Cab w/ 165" Wheelbase & Diesel)	030 203	030 244		
1990	D-200, D-250 w/ Heavy Duty Package, Crew Cab w/ 165" Wheelbase & Diesel	030 245	030 244		
72-80	D-200, D-300 w/ Heavy Duty Package & Crew Cab w/ 165" Wheelbase	030 245	030 244		
84-89	D-250, D-350 (D-250 w/ HD Package & 165" Wheelbase)	030 245	030 244		
81-89	D-250 (Exc. Heavy Duty Package & Crew Cab w/ 165" Wheelbase)	030 203	030 244		
81-83	D-250, D-350 Heavy Duty Package w/ 165" Wheelbase	030 245	030 244		
72-80	D-250 (Exc. Heavy Duty Package & Crew Cab w/ 165" Wheelbase)	030 203	030 244		

D50, RAM 50 PICKUP

79-93	2WD	030 266	030 222		
-------	-----	---------	---------	--	--

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
DODGE (Continued)					
D50, RAM 50 PICKUP (Continued)					
82-93	4WD	030 255	030 222		
DAKOTA (N BODY)					
97-00	2WD	030 265	030 767		
	4WD	030 852	030 767		
86-96	2WD	030 265	030 260		
	4WD	030 852	030 263		
DAYTONA (G BODY)					
86-94	All (Mfg. after Jan/86, exc. Shelby)	030 005	030 228	802 703(*)	
84-86	All (Mfg. to Jan/86)	030 015	030 228	802 702(*)	
DIPLOMAT (M BODY)					
77-89	All	030 235	030 268		
DURANGO					
98-00	4WD	030 852	030 767		
DYNASTY (C BODY)					
88-94	All (Exc. Self Leveling System)	030 005	030 228		
INTREPID (LH)					
98-00	All				
	Left Side	030 635	030 694		
	Right Side	030 636	030 694		
93-97	All				
	Left Side	030 635	030 637	802 730(*)	802 751
	Right Side	030 636	030 637	802 730(*)	802 751
LANCER (H BODY)					
86-89	All (Mfg. after Jan/86)	030 004	030 228	802 836	
				802 703(*)	
85-86	All (Mfg. to Jan/86)	030 015	030 228	802 702(*)	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
DODGE (Continued)					
M & RM SERIES MOTORHOME CHASSIS					
78-81	M-300, M-400, M-500 & M-600	030 769	030 241		
75-77	M-300 (M3), M-400 (M4) & M-500 (M5)	030 769			
73-74	RM-300 (R3), RM-400 (R4) & RM-500 (R5)	030 769			
MIRADA (M BODY)					
80-83	All	030 235	030 268		
MONACO, POLARA					
77-78	All M Body (Exc. Police Package)	030 701	030 268		
74-76	All	030 235	030 812		
1973	All (Exc. Station Wagon)	030 813	030 812		
1972	All	030 813	030 812		
65-70	All	030 813	030 812		
1971	All	030 813			
90-92	Monaco All BB Body		030 820	802 811(*)	
1977	Royal Monaco	030 235	030 812		
1973	Station Wagon	030 813			
NEON					
94-99	All	030 012	030 013	802 762	802 769
OMNI, CHARGER (L-BODY)					
78-90	All			802 700(*)	
81-89	All	030 011	030 745		
78-80	All	030 011	030 742		
1990	4Dr.	030 618	030 745		
RAIDER					
1989	4WD w/ V6	030 255	030 771		
87-89	4WD w/ 4 cyl.	030 255	030 262		
RAM PICKUP (T SERIES)					
94-00	2WD 1500, 2500, 3500 (Exc. 3500 HD w/ Solid Front Axle)	030 781	030 867		
	2WD 3500 w/ Solid Front Axle	030 785	030 786		
	4WD 1500, 2500 (Exc. 2500 w/ 8800 lb GVW & Diesel)	030 784	030 782		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
DODGE (Continued)					
RAM PICKUP (T SERIES) (Continued)					
94-99	4WD 2500 w/ 8800 lb GVW or Diesel, 3500	030 785	030 786		
RAMCHARGER					
75-93	2WD	030 203	030 244		
76-93	4WD	030 241	030 249		
74-75	4WD	030 241	030 244		
RAMPAGE					
82-85	All	030 011	030 721		
RD MODELS					
78-80	RD 200	030 241	030 249		
SHADOW (P BODY)					
86-94	All (Mfg. after Jan/86)	030 005	030 228	802 703(*)	
SPIRIT (A BODY)					
89-95	All	030 005	030 228	802 703(*)	
ST. REGIS					
79-81	All	030 701	030 268		
STEALTH					
91-96	2WD (Exc. Electronic Suspension)			802 809(*)	
	2WD w/ Electronic Suspension			802 809(*)	
	4WD			802 809(*)	
STRATUS					
2000	All w/o Bracket	030 667	030 747	802 816	802 771
95-99	All	030 667	030 747	802 816	802 771
W SERIES - 4WD PICKUP					
85-93	W-100 (Exc. Lift Kit)	030 241	030 249		
72-80	W-100, W-150, W-200, W-300, W-400	030 241	030 249		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
DODGE (Continued)					
W SERIES - 4WD PICKUP (Continued)					
61-71	W-100, W-200	030 241	030 241		
81-93	W-150 (Exc. Lift Kit), W-250 (Exc. Crew Cab & Lift Kit)	030 241	030 249		
61-71	W-300, WM-300	030 241	030 241		
84-90	W-350 (Exc. Quad Shock & Lift Kit)	030 241	030 249		
81-83	W-350 (Exc. Quad Shock & Lift Kit)	030 241	030 249		
400					
1983	All			802 701(*)	
82-83	All	030 011	030 228		
1982	All			802 700(*)	
600 (E BODY)					
86-88	All (Mfg. after Jan/86)	030 005	030 228	802 703(*)	
84-86	All (Mfg. to Jan/86)	030 015	030 228	802 702(*)	
1983	All	030 011	030 228	802 701(*)	
EAGLE					
PREMIER (BB)					
88-92	All Premier, Medalion Sedan		030 820	802 811(*)	
SUMMIT					
93-97	All (Exc. Station Wagon)	030 672	030 746	802 767(*)	
93-96	All				802 806
89-92	All				802 806
92-95	DL Wagon	030 627	206 61A	802 758	802 806
89-92	4Dr. Sedan	030 616	030 743	802 745	
1990	3Dr. Hatchback	030 616		802 745	
TALON					
95-99	AWD	030 668			
	FWD	030 668	030 748		
91-94	AWD	030 627	030 749	802 731	802 806
	FWD	030 627	030 749	802 731	802 806
1990	AWD	030 614	030 744	802 731	802 806
	FWD	030 614	030 749	802 731	802 806

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
EAGLE (Continued)					
VISION (LH)					
93-97	All				
	Left Side	030 635	030 637	802 730(*)	802 751
	Right Side	030 636	030 637	802 730(*)	802 751
FIAT					
X 1/9					
74-78	All	203 05A			
FORD					
AEROSTAR					
89-97	2WD	030 209	030 225		
90-97	4WD	030 774	030 225		
86-88	All	030 209	030 259		
ASPIRE					
95-97	All (Exc. ABS)	030 659	030 822	802 721	
BRONCO					
80-96	All (Exc. Bronco II, Quad Susp. & Lift Kit)	030 208	030 252		
87-88	All w/ 3-4" Lift Kit (Exc. Bronco II)		030 761		
80-86	All w/ 3-4" Lift Kit (Exc. Quad Suspension, Bronco II)	030 763	030 761		
80-85	All w/ 3-4" Lift Kit (Quad Suspension)				
	Forward of Front Axle (2 reqd.)	030 764			
	Rearward of Front Axle (2 reqd.)	030 763			
78-79	All w/ 3 1/2-4" Lift Kit (Exc. Quad Suspension)				
	Left Side	030 853	030 761		
	Right Side	030 763	030 761		
66-77	All from Serial No. 830001 (Exc. Lift Kit)	030 205	030 247		
	All w/ 4-5" Lift Kit	030 763	030 761		
1990	Bronco II	030 220	030 238		
1989	Bronco II (Mfg. from Feb/89, vehicles w/ 12 mm bolt in rear lower mount)	030 208	030 238		
83-89	Bronco II (Mfg. to Jan/89, vehicles w/ 10 mm bolt in rear lower mount)	030 208	030 237		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
FORD (Continued)					
BRONCO (Continued)					
80-95	Quad Suspension (Exc. Bronco II & Lift Kit)				
	Forward of Front Axle (2 reqd.)	030 253	030 252		
	Rearward of Front Axle (2 reqd.)	030 208	030 252		
78-79	Std. & Quad Suspension (Exc. Lift Kit)				
	Left Side	030 753	030 247		
	Right Side	030 205	030 247		
CONTOUR					
95-00	All	030 643	030 644	802 772	802 775
COURIER, PICKUP					
72-82	All	030 209	030 717		
E SERIES VAN					
75-91	E-100, E-150	030 264	030 243		
68-74	E-100, E-200, E-300 (Late 1968)	030 842	030 247		
92-00	E-150	030 800	030 777		
	E-250, E-350	030 775	030 776		
75-91	E-250, E-350, E-350 w/ Motorhome Conversion	030 205	030 248		
ESCORT, EXP					
98-00	All (Exc. AWD & ABS)			802 723	
91-00	All (Exc. 4WD & ABS)				
	Left Side	030 619	030 621		
	Right Side	030 620	030 622		
91-97	All			802 723	802 725
81-83	All (Mfg. before Feb/83)	030 649	030 650	802 760	802 733
83-85	All (Mfg. between Feb/83 and Mar/85)	030 652	030 650	802 760	802 733
85-90	Escort (Mfg. after March/85)	030 006	030 650	802 711(*)	802 733
				802 837	
91-00	4WD				
	Left Side	030 619			
	Right Side	030 620			
EXCURSION					
2000		TBA			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear

FORD (Continued)

EXPEDITION

97-00	2WD (Exc. Air Leveling)	030 793	030 796		
	4WD (Exc. Air Leveling)	030 795	030 796		

EXPLORER

95-00	All (Exc. Adjustable Suspension)	030 788	030 789		
91-94	All	030 219	030 218		

F SERIES - 2WD PICKUP

80-84	F-100, F-150	030 208	030 252		
70-79	F-100, F-150, F-250 (Exc. Crew Cab)	030 205	030 243		
97-00	F-150, F-250 (Exc. Super Duty)	030 793	030 862		
85-96	F-150	030 208	030 206		
99-00	F-250, F-350 Super Duty	030 860	030 861		
80-98	F-250, F-350 (Exc. F-350 w/ Dual Rear Wheels)	030 208	030 206		
73-79	F-250 Crew Cab, F-350 (Exc. w/ Rear Stabilizer Bar or Super Cab)	030 205	030 247		
80-98	F-350 w/ Dual Rear Wheels	030 208	030 252		
78-79	F-350 w/ Rear Stabilizer Bar (Exc. Super Cab)	030 205	030 247		
74-79	F-350 Supercab	030 205	030 243		
73-77	F-350 w/ Rear Stabilizer Bar (Exc. Super Cab)	030 205	030 247		
67-72	F-350	030 205	030 247		
93-98	F-450 (Mfg. from Feb/93)	030 792	030 252		
88-93	F-450 (Mfg. to Feb/93)	030 773	030 252		

F SERIES - 4WD PICKUP

77-79	F-100, F-150 w/ 3-4" Lift Kit (Exc. Quad Suspension & Super Cab)	030 763	030 853		
70-76	F-100, F-150 w/ 3 1/2-4" Lift Kit		030 853		
	F-100, F-150 (Exc. Lift Kit)	030 843	030 248		
97-99	F-150, F-250 (Exc. Super Duty)	030 795	030 794		
80-96	F-150 (Exc. Quad Suspension & Lift Kit)	030 208	030 215		
	F-150 Quad Suspension (Exc. Lift Kit)				
	Forward of Front Axle (2 reqd.)	030 253	030 215		
	Rearward of Front Axle (2 reqd.)	030 208	030 215		
80-86	F-150 w/ 3-4" Lift Kit (Quad Suspension)				
	Forward of Front Axle (2 reqd.)	030 764	030 759		
	Rearward of Front Axle (2 reqd.)	030 763	030 759		
80-85	F-150 w/ 3-4" Lift Kit (Exc. Quad Suspension)	030 763	030 759		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
FORD (Continued)					
F SERIES - 4WD PICKUP (Continued)					
78-79	F-150 Super Cab (Exc. Lift Kit)	030 755		030 248	
	F-150 Quad Susp. (Exc. Super Cab & Lift Kit)				
	Forward of Front Axle (2 reqd.)	030 753		030 248	
	Rearward of Front Axle (2 reqd.)	030 205		030 248	
77-79	F-150 Std. Susp. (Exc. 1978-79 Supercab & Lift Kit)	030 205		030 248	
99-00	F-250, F-350 Super Duty (Forward of Rear Axle)	030 863		030 865	
	F-250, F-350 Super Duty (Rearward of Front Axle)	030 863		030 864	
97-98	F-250 (Over 8500 lb GVW)	030 257		030 215	
87-96	F-250	030 257		030 215	
1986	F-250	030 254		030 215	
82-85	F-250, F-350 w/ Clevis Type Lower Front Mount (Exc. w/ Dual Rear Wheels or Lift Kit)	030 254		030 215	
80-82	F-250 (Early 82, exc. Supercab)	030 253		030 215	
	F-250 Super Cab	030 254		030 215	
77-79	F-250 from Serial No. Y20001 (Exc. Crew Cab)	030 755		030 248	
66-77	F-250 up to Serial No. Y20000	030 751			
86-98	F-350 (Exc. w/ Dual Rear Wheels & Lift Kit)	030 257		030 766	
	F-350 w/ Dual Rear Wheels	030 257		030 215	
80-81	F-350 (Exc. w/ Dual Rear Wheels & Lift Kit)	030 253		030 215	
1979	F-350 (Exc. w/ Dual Wheels)	030 755		030 248	
FAIRLANE, TORINO, ELITE, LTD, LTD II					
83-86	LTD	030 002	⚙️	030 232	802 728
72-79	All	030 229		030 232	
FAIRMONT, FUTURA					
82-83	All (Exc. Police Package)				802 728
78-83	All	030 002	⚙️	030 232	
81-82	All w/ TRX Suspension				802 728
FESTIVA					
87-94	All (Exc. ABS)	030 659	⚙️	030 822	802 721
FIESTA					
78-80	All	030 647	⚙️	030 648	⚙️
FOCUS					
2000		TBA			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
FORD (Continued)					
FULL SIZE					
65-82	All	030 229	030 232		
83-00	Crown Victoria, Country Squire, Station Wagon	030 229	030 232		
	Crown Victoria (Police & Taxi Models)	030 204	030 232		
GRANADA					
81-82	All	030 002	030 232	802 728	
75-80	All	030 705	030 815		
MAVERICK					
69-77	All	030 270	030 815		
MUSTANG, MUSTANG II					
94-00	All (Exc. Cobra)	030 641	030 731		
83-96	All			802 728	
83-93	All (Exc. SVO, GT & LX w/ 5.0L Engine)	030 002	030 232		
79-82	All (Exc. 1982 GT)	030 002	030 232		
74-78	All (Mfg. from Nov/73)	030 823	030 824		
1974	All (Mfg. to Nov/73)	030 823			
71-73	All	030 705	030 271		
67-70	All	030 270	030 271		
65-66	All	030 826	030 271		
87-93	GT & LX w/ 5.0L Engine	030 610	030 712		
84-86	SVO	030 739	030 712		
PINTO					
71-80	All (Exc. Station Wagon)	030 823	030 828		
72-80	Station Wagon	030 823			
PROBE					
89-92	All (Exc. Elec. Adj. Susp.)	030 623	030 624		802 723
93-97	GL & LX				
	Left Side	030 638	030 640	802 742	802 776
	Right Side	030 639	030 640	802 742	802 777
89-92	Manual Transmission (Exc. Elec. Adj. Susp. & Auto. Transmission, 3.0L, V6, mfg. from May/91)			802 722	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
FORD (Continued)					
RANCHERO					
72-79	All	030 229	030 232		
RANGER					
98-00	2WD	030 847	030 848		
90-97	2WD	030 220	030 238		
1989	2WD (Mfg. from Feb/89, vehicles w/ 12 mm bolt in rear lower mount)	030 208	030 238		
83-89	2WD (Mfg. to Jan/89, vehicles w/ 10 mm bolt in rear lower mount)	030 208	030 237		
98-00	4WD	030 851	030 849		
90-97	4WD	030 220	030 770		
1989	4WD (Mfg. from Feb/89, vehicles w/ 12 mm bolt in rear lower mount, exc. High Ryder Option)	030 208	030 770		
	4WD w/ High Ryder option (Mfg. from Feb/89, vehicles w/ 12 mm bolt in rear lower mount)	030 772	030 770		
87-89	4WD (Mfg. to Jan/89, vehicles w/ 10 mm bolt in rear lower mount, exc. High Ryder Option)	030 208	030 256		
	4WD w/ High Ryder Option (Mfg. to Jan/89, vehicles w/ 10 mm bolt in rear lower mount)	030 772	030 256		
83-86	4WD	030 208	030 256		
TAURUS					
96-00	All (Exc. SHO & Station Wagon)	030 670	030 671	802 774	802 750
86-95	All (Exc. Station Wagon, SHO, and Police Car)	030 630	030 605		
91-95	All (Exc. Station Wagon Rear)			802 712(*)	802 750
86-90	All (Exc. Station Wagon)			802 712(*)	802 705
96-00	SHO Semi-Active Suspension				
	Left Side	030 048	030 050		
	Right Side	030 047	030 049		
86-95	SHO (Incl. Police Car)	030 045	030 046		
96-00	Station Wagon	030 670	030 854		
86-95	Station Wagon	030 630	030 269		
TEMPO					
84-94	All			802 711(*) 802 837	802 709
84-85	All (Mfg. to Mar/85)	030 014	030 007		
85-94	2WD (Mfg. from Mar/85)	030 006	030 007		
87-91	4WD	030 006	030 656		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
FORD (Continued)					
THUNDERBIRD					
92-97	All (Exc. Elec. Adj. Susp.)	030 613	⚙️ 030 729		
89-97	All (Exc. Elec. Adj. Susp.)			802 734	
89-91	All (Exc. Elec. Adj. Susp.)	030 613	⚙️ 030 728		
87-88	All (Exc. Turbo and V8)	030 002	⚙️ 030 233		
80-88	All			802 732	
80-86	All	030 016	⚙️ 030 233		
77-79	All	030 229	030 232		
73-76	All	030 229	030 829		
67-72	All	030 229	030 232		
64-66	All		030 830		
59-60	All	030 831			
55-57	All	030 832	030 271		
WINDSTAR					
95-00	All	030 642	⚙️ 030 787	802 773(*)	
GEO					
METRO					
89-95	All w/o Brakeline Bracket Welded on Strut Housing	030 662	⚙️ 030 660	802 752	802 754
PRIZM					
93-97	All				
	Left Side	030 631	⚙️ 030 633		802 739
	Right Side	030 632	⚙️ 030 634		802 740
89-92	All				
	Left Side	030 615	⚙️ 030 611		802 739
	Right Side	030 615	⚙️ 030 611		802 740
SPECTRUM					
1989	All	030 655	⚙️ 030 709	802 741	
STORM					
90-93	All w/ ABS	030 695	⚙️	802 764	
	All (Exc. ABS)	030 663	⚙️ 030 661	802 764	802 768

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear

GEO (Continued)

TRACKER

89-97	All				
	Left Side	030 628	030 801	802 753	
	Right Side	030 629	030 801	802 753	

GMC TRUCK

C & R SERIES 2WD PICKUP & SUBURBAN

99-00	C-1500 w/ New Body Style	030 846	030 782		
92-00	C-1500, C-2500 Suburban	030 217	030 780		
88-99	C-1500, C-2500, C-3500 Pickup (Exc. Crew Cab)	030 217	030 216		
73-86	C-1500	030 223	030 201		
67-72	C-1500 w/ Rear Coil Springs	030 223	030 837		
	C-1500 w/ Rear Leaf Springs	030 223	030 242		
85-86	C-2500, C-3500, Crew Cab & Bonus Cab	030 223	030 246		
73-86	C-2500 (Exc. Crew Cab & Bonus Cab)	030 223	030 201		
73-84	C-2500 Crew & Bonus Cab	030 223	030 246		
67-72	C-2500 w/ Rear Coil Springs	030 223	030 837		
	C-2500 w/ Rear Leaf Springs	030 223	030 242		
96-00	C-3500 Heavy Duty w/ Solid Front Axle	030 855	030 216		
73-84	C-3500	030 223	030 246		
67-72	C-3500 w/ 11,000 lb Rear Axle	030 223			
	C-3500 (Exc. 11,000 lb Rear Axle)	030 223	030 242		
88-91	R-1500, R-2500 Suburban	030 223	030 201		
1987	R-1500, R-2500 (Exc. Crew Cab & Bonus Cab)	030 223	030 201		
88-90	R-2500, R-3500 Pickup Crew Cab; Cab/Chassis	030 223	030 246		
1987	R-2500, R-3500, Crew Cab & Bonus Cab	030 223	030 246		

ENVOY

98-00		TBA			
-------	--	-----	--	--	--

G SERIES - VANS & HANDI-VAN

96-00	G-1500, G-2500 Savana Van (Exc. G-2500 w/ 8600 lb GVW)	030 204	030 780		
78-95	G-1500	030 202	030 207		
71-77	G-1500, G-2500 & G-3500 (Exc. G-3500 w/ 146" Wheelbase)		030 242		
1970	G-1500, G-2500, w/ I-Beam Front Axle		030 242		
	G-1500, G-2500 w/ Independent Front Suspension	030 202	030 242		
78-95	G-2500 (Exc. 8600 lb GVW)	030 202			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
GMC TRUCK (Continued)					
G SERIES - VANS & HANDI-VAN (Continued)					
97-00	G-3500 All	030 204	030 780		
92-96	G-3500 w/ 7100 lb w/ Chassis Cab, 7400 lb, or 8600 lb GVW	030 202	030 783		
79-96	G-3500 w/ 9200 lb GVW	030 202	030 767		
78-96	G-3500 (Exc. 7100 lb w/ Chassis Cab, 7400 lb, 8600 lb & 9200 lb GVW)	030 202	030 207		
75-77	G-3500 w/ 146" Wheelbase	030 202			
JIMMY					
83-99	S-15 2WD	030 209	030 210		
	S-15 4WD	030 211	030 210		
73-84	2WD	030 223	030 201		
70-72	2WD w/ Rear Coil Springs	030 223	030 837		
	2WD w/ Rear Leaf Springs	030 223	030 242		
81-91	4WD Quad Suspension (Exc. S-15 & Lift Kit)				
	Long Shock Front (2 reqd.)	030 207	030 201		
	Short Shock Front (2 reqd.)	030 200	030 201		
73-91	4WD (Exc. Quad Suspension, S-15 & Lift Kit)	030 200	030 201		
73-90	4WD w/ 4" Lift Kit (Exc. Quad Suspension & S-15)	030 757	030 758		
71-72	4WD	030 200	030 754		
1970	4WD	030 200			
K & V SERIES 4WD PICKUP & SUBURBAN					
99-00	K-1500 w/ New Body Style	030 856	030 756		
92-00	K-1500, K-2500 Suburban	030 221	030 780		
88-99	K-1500 (Incl. Z-71)	030 857	030 216		
81-86	K-1500, K-2500 Quad Suspension (Exc. Lift Kit)				
	Long Shock Front (2 reqd.)	030 207	030 201		
	Short Shock Front (2 reqd.)	030 200	030 201		
73-86	K-1500, K-2500 (Exc. Quad Suspension & Lift Kit)	030 200	030 201		
	K-1500, K-2500 w/ 4" Lift Kit (Exc. Quad Suspension)	030 757	030 758		
71-72	K-1500, K-2500	030 200	030 754		
69-70	K-1500, K-2500	030 200			
88-99	K-2500, K-3500 Pickup	030 221	030 216		
77-86	K-3500	030 768	030 756		
96-99	K-3500 (Exc. Crew Cab)	030 221			
88-91	V-1500 Suburban (Exc. Quad Suspension & Lift Kit)	030 200	030 201		
	V-1500, V-2500 Suburban w/ 4" Lift Kit Shocks Mounted Behind Front Axle (Exc. Quad Susp.)	030 757	030 758		
	V-1500, V-2500 Suburban w/ Quad Suspension (Exc. Lift Kit)				

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
GMC TRUCK (Continued)					
K & V SERIES 4WD PICKUP & SUBURBAN (Continued)					
	Long Shock Front (2 reqd.)	030 207	030 201		
	Short Shock Front (2 reqd.)	030 200	030 201		
1987	V-1500, V-2500 (Exc. Quad Suspension & Lift Kit)	030 200	030 201		
	V-1500, V-2500 Quad Suspension (Exc. Lift Kit)				
	Long Shock Front (2 reqd.)	030 207	030 201		
	Short Shock Front (2 reqd.)	030 200	030 201		
	V-1500, V-2500 w/ 4" Lift Kit; Shocks Mounted Behind Front Axle (Exc. Quad Suspension)	030 757	030 758		
88-91	V-2500 Suburban (Exc. Quad Suspension & Lift Kit)	030 200	030 201		
87-91	V-3500 (Incl. Pickup Crew Cab; Cab/Chassis)	030 768	030 756		
P SERIES - PANEL FORWARD CONTROL & VALUE VAN					
74-80	P-1500	030 223	030 246		
1973	P-1500	030 223	030 201		
67-72	P-1500	030 223	030 837		
79-90	P-2500	030 223	030 246		
73-78	P-2500	030 223	030 201		
68-72	P-2500	030 223	030 242		
86-99	P-3500 Motorhome Chassis w/ I-Beam Front Susp.	030 778	030 246		
74-99	P-3500 Motorhome Chassis w/ Ind. Front Susp.	030 250	030 246		
73-90	P-3500 (Exc. Motorhome Chassis)	030 223	030 246		
1985	P-3500 Motorhome Chassis w/ I-Beam Front Susp.	030 767	030 246		
68-72	P-3500 w/ 11,000 lb Rear Axle	030 223			
	P-3500 (Exc. 11,000 lb Rear Axle)	030 223	030 242		
S SERIES PICKUP					
82-99	S-15 Sonoma 2WD	030 209	030 210		
83-99	S-15 Sonoma 4WD	030 211	030 210		
SAFARI VAN					
85-90	All	030 204	030 214		
91-00	2WD	030 204	030 214		
	4WD	030 221	030 214		
SPRINT, CABALLERO, DIABLO PICKUP DELIVERY					
71-87	All	030 209	030 227		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
GMC TRUCK (Continued)					
YUKON					
2000	Denali, XL	TBA			
92-00	C-1500 2WD	030 217	030 780		
	K-1500 4WD	030 221	030 780		
HONDA					
ACCORD					
94-97	All	207 79A	207 88A		
79-97	All				802 726
86-95	All			802 816	
90-93	All (Exc. Station Wagon)	207 79A	207 80A		
82-85	All	207 03A	207 04A	802 743(*)	
79-81	All	207 00A	207 01A		
75-78	All	207 00A			
86-89	DX, LX 2 & 4Dr.	207 62A	207 63A		
91-93	Station Wagon	207 79A	207 88A		
CIVIC					
96-99	All	208 59A	208 60A		
88-97	All			802 816	802 816
92-95	All	208 01A	208 02A		
89-91	All (Exc. Wagon)	207 78A	207 76A		
1988	All (Exc. Wagon)	207 72A	207 73A		
84-87	All (Exc. 4WD)			802 744	802 726
	All (Exc. Wagon)	207 50A	205 07A		
80-83	All (Exc. Station Wagon)				802 726
	All (Exc. Wagon)	207 41A	207 42A		
89-91	Wagon	207 84A	207 85A		
80-83	Wagon	207 41A			
1988	Wagon	207 69A	207 70A		
84-87	Wagon 2WD	207 57A	205 07A		
	Wagon 4WD	207 53A	200 17A		
CR-V					
97-00		TBA			
CRX					
89-91	All	207 89A	208 02A		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
HONDA (Continued)					
CRX (Continued)					
1988	All	207 72A	207 73A		
84-87	All	207 50A	205 07A		
DEL SOL					
92-97	All	208 01A	208 02A		
INSIGHT					
2000		TBA			
ODYSSEY					
95-99	All		208 46A		
PASSPORT					
98-99	All	206 24A	206 57A		
94-97	All	206 24A	030 232		
PRELUDE					
92-98	All	208 11A	208 04A	802 816	802 726
88-91	All	207 71A	207 68A	802 816	
83-87	All w/ Rebuildable Rear Struts	207 48A	203 20A	802 816	802 726
	All w/ Sealed Rear Struts	207 48A	207 04A		
79-82	All	203 17A	203 06A		802 726
S2000					
2000		TBA			
HYUNDAI					
ACCENT					
6/97-99	All	208 99A			
95-5/97	All	208 99A	209 00A		
ELANTRA					
92-95	All (Exc. ABS)	030 616	030 743	802 745	802 806

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
HYUNDAI (Continued)					
EXCEL					
86-89	All			802 749(*)	
	All w/ Rebuildable Front Struts	203 36A	030 274		
90-94	Hatchback, 4Dr. Sedan	207 18A	030 274	802 763	
PONY					
84-87	All		030 274		
SCOUPE					
91-96	All	207 18A	030 274	802 763	
SONATA					
95-98	All			802 831(*)	
89-94	All	208 44A	205 15A	802 758	
TIBURON					
97-00		TBA			
INFINITI					
G20					
99-00		TBA			
I30					
95-99	All				
	Left Side	208 71A	205 31A		
	Right Side	208 72A	205 31A		
QX-4					
98-00	All				
	Left Side	209 09A	206 58A		
	Right Side	209 10A	206 58A		
Q45					
90-00		TBA			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
ISUZU					
AMIGO					
89-95	All	030 706	030 262		
HOMBRE					
96-99	All (Exc. Sport Chassis)	030 209	030 210		
I-MARK					
88-89	All	030 665			
85-89	All (Exc. Lotus Suspension)	030 655	030 709	802 741	
1982	Sedan	030 272			
1981	Sedan	030 272	030 718		
IMPULSE					
83-89	All (Exc. Lotus Suspension)	030 272	030 273		
90-94	2 & 4WD (Exc. ABS)				
	Left Side	207 99A		802 764	802 768
	Right Side	208 00A		802 764	802 768
OASIS					
96-99	All	207 79A	208 46A		
PICKUP					
81-95	2WD	030 236	030 262		
	4WD	030 706	030 262		
RODEO					
98-99	All	206 24A	206 57A		
91-97	2 & 4WD	206 24A	030 232		
STYLUS					
91-94	All w/ Disc Brakes (Exc. Lotus Suspension)				
	Left Side	207 99A		802 764	802 768
	Right Side	208 00A		802 764	802 768

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
ISUZU (Continued)					
TROOPER					
92-99	4WD	206 55A	206 56A		
89-91	4WD	206 15A	206 16A		
87-88	4WD	206 08A	206 11A		
84-86	4WD	030 706	030 262		
VEHICROSS					
99-00		TBA			
JAGUAR					
75-96	XJS (2 Rear Shocks reqd.)	363 020	363 030		
10/86-96	XJ40 Sovereign, Vandenplas	361 460	368 006	⌄	
10/86-94	XJ40 (New XJ6)	361 460	460 550		
68-86	XJ6, XJ12 (2 Rear Shocks reqd.)	363 020	363 030		
61-74	XKE 6 cyl. (2 Rear Shocks reqd.)		262 59G		
JEEP					
CHEROKEE, WAGONEER (XJ)					
84-00	All	030 212	030 224		
CJ & DJ SERIES, UNIVERSAL JEEP					
82-86	CJ-5, CJ-7 & Scrambler (Exc. Lift Kit)	030 247	030 222		
	CJ-5, CJ-7 w/ 2" Lift Kit	030 761	030 762		
	CJ-5, CJ-7 w/ 3-4" Lift Kit	030 761	030 760		
76-81	CJ-5, CJ-7 & Scrambler (Exc. Lift Kit)	030 752	030 222		
	CJ-5, CJ-7 w/ 2-4" Lift Kit	030 762	030 760		
72-75	CJ-5, CJ-6, DJ-5 & DJ-6 (Exc. Lift Kit)	030 752	030 222		
65-75	CJ-5, CJ-6, DJ-5, DJ-6 w/ 2-4" Lift Kit	030 762	030 760		
65-71	CJ-5, CJ-6, DJ-5 & DJ-6 (Exc. CJ Models w/ 5 Leaf Front Springs & Lift Kit)	030 845	030 222		
55-71	CJ-5, CJ-6 w/ 5 Leaf Front Springs (Exc. Lift Kit)	030 818	030 818		
COMANCHE					
87-92	All	030 212	030 262		
1986	2WD	030 212	030 222		
	4WD	030 212	030 262		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
JEEP (Continued)					
COMMANDO / JEEPSTER					
70-73	All	030 845	030 222		
GLADIATOR & PIONEER PICKUP					
84-88	J-10, J-20	030 247	030 247		
80-83	J-10, J-20	030 247	030 247		
74-79	J-10, J-20	030 247	030 247		
69-73	J-2000, J-3000 & J-4000		030 247		
GRAND CHEROKEE (ZJ)					
95-00	All	030 212	030 790		
93-94	All	030 212	030 779		
GRAND WAGONEER / CHEROKEE (SJ)					
76-83	All	030 247	030 247		
1975	All	030 247			
1974	All	030 247	030 818		
1973	All	030 262	030 818		
84-91	Grand Wagoneer	030 247	030 247		
63-72	All (Exc. 1963-65 Independent Front Suspension)	030 262	030 752		
WRANGLER					
97-00	All (TJ)	030 797	030 798		
87-96	All (YJ)	030 713	030 261		
KIA					
SPORTAGE					
98-99	All		206 59A		
95-97	All	205 35A	206 59A		
LEXUS					
ES 250					
90-92	All	207 22A	207 21A		802 820

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
LEXUS (Continued)					
ES 300					
95-96	All Left Side Right Side		030 024 030 023	802 828(*) 802 828(*)	802 829 802 829
92-94	All				
	Left Side	208 28A	030 024	802 828(*)	802 829
	Right Side	208 29A	030 023	802 828(*)	802 829
	All w/ Rebuildable OE Struts	203 47A			
GS 300					
98-00		TBA			
GS 400					
98-00		TBA			
LS 400					
98-00		TBA			
LX 450					
96-97	All	206 25A	206 26A		
LX 470					
98-00		TBA			
RX 300					
99-00		TBA			
SC 300					
92-00		TBA			
SC 400					
92-00		TBA			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
LINCOLN					
CONTINENTAL					
97-00	All w/ Passive Suspension				
	Left Side	030 042	030 043		
	Right Side	030 041	030 043		
	All w/ Semi-Active Suspension				
	Left Side	030 038	030 039		
	Right Side	030 037	030 039		
95-96	All w/ Semi-Active Suspension				
	Left Side	030 034	030 039		
	Right Side	030 033	030 039		
88-93	All w/ Air Suspension				
	Left Side	030 689	030 691		
	Right Side	030 690	030 691		
82-87	All	030 603	030 233	802 732	
70-81	All	030 229	030 232		
LS					
2000		TBA			
MARK III, MARK IV, MARK V, MARK VI, MARK VII					
68-71	Mark III	030 229	030 232		
73-77	Mark IV	030 229	030 829		
1972	Mark IV	030 229	030 232		
77-79	Mark V	030 229	030 829		
80-83	Mark VI	030 229	030 232		
84-93	Mark VII	030 603	030 233	802 732	
NAVIGATOR					
98-00		TBA			
TOWN CAR					
82-00	All (Exc. Air Suspension)	030 229	030 232		
VERSAILLES					
77-80	All	030 705	030 815		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
MAZDA					
B SERIES					
98-00	2WD	030 847	030 848		
94-97	2WD	030 220	030 238		
98-00	4WD	030 851	030 849		
94-97	4WD	030 220	030 770		
GLC					
81-85	All (Exc. Wagon)	030 651	030 608	802 720	802 724
1980	All (Exc. Wagon)	203 04A	201 01A		
77-79	All (Exc. OE Struts)		201 01A		
80-83	Wagon	203 04A	030 271		
78-79	Wagon (Exc. OE Struts)		030 271		
MPV VAN					
89-98	2WD	207 93A	206 20A		
	4WD (Exc. Self Leveling System)	207 94A	206 38A		
MIATA					
90-00	All (w/o ABS)	205 22A	205 23A	802 807	802 807
MILLENNIA					
95-00		TBA			
MX MODELS					
92-95	MX3 (Incl. ABS)			802 723	802 725
93-97	MX6				
	Left Side	030 638	030 640	802 742	802 776
	Right Side	030 639	030 640	802 742	802 777
88-92	MX6 (Front Only, exc. Elec. Adj. Susp., 4WD and Automatic Transmission)			802 722	802 727
	MX6 (Exc. Elec. Adj. Susp.)	030 623	030 624		
NAVAJO					
91-94	All	030 219	030 218		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
MAZDA (Continued)					
PICKUP					
72-84	All	030 209	030 717		
86-93	2WD	206 08A	030 222		
87-93	4WD	206 36A	206 37A		
PROTÉGÉ					
96-98	All			802 839	
90-95	All			802 723	802 725
90-94	All (Exc. 4WD & ABS)				
	Left Side	030 619	030 621		
	Right Side	030 620	030 622		
	4WD				
	Left Side	030 619			
	Right Side	030 620			
RX MODELS					
86-92	All (Exc. Elec. Adj. Susp.)	207 13A	205 03A		
78-80	All	203 01A	202 01A		
81-85	All (Exc. GSL-SE)	203 07A	202 01A		
	GSL-SE	203 15A	202 01A		
323					
90-95	All			802 723	802 725
90-94	2WD				
	Left Side	030 619	030 621		
	Right Side	030 620	030 622		
86-89	2WD (Exc. Turbo & Elec. Adj. Susp.)	030 651	030 608	802 720	802 724
90-94	4WD				
	Left Side	030 619			
	Right Side	030 620			
626					
93-98	All				
	Left Side	030 638	030 640	802 742	802 776
	Right Side	030 639	030 640	802 742	802 777
88-92	All (Exc. Elec. Adj. Susp.)	030 623	030 624		802 727
86-87	All (Exc. Elec. Adj. Susp. & Auto. Transmission)			802 714	
83-87	All (Exc. Elec. Adj. Susp.)	207 52A	207 54A		
83-85	FWD, Coupe, Sedan (Exc. Elec. Adj. Susp.)			802 714	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
MAZDA (Continued)					
626 (Continued)					
88-92	Manual Transmission (Exc. Elec. Adj. Susp.)			802 722	
808					
71-77	Wagon		030 271		
929					
90-91	All (Exc. Elec. Adj. Susp.)	207 95A	⚙️	205 20A	
88-89	All (Exc. Elec. Adj. Susp.)	207 92A	⚙️	205 20A	
MERCEDES BENZ					
190 MODELS					
62-65	190C, DC (W110)	603 102		604 102 700 001	⚙️
11/82-93	190D, 2.5L, E w/ Standard Suspension (W201)	366 12B	⚙️	361 191 102 806 102 807	⚙️ ⚙️ ⚙️
	190D, 2.5L, E w/ Sport Suspension (W201)	366 12C	⚙️	36A 050 102 807	⚙️ ⚙️
84-89	190E 16V 2.3L (W201)	366 12C	⚙️	102 808	⚙️
200 MODELS					
85-93	200, D, E (Exc. 4-Matic) (W124)	361 11B	⚙️	361 201 102 809 102 810	⚙️ ⚙️ ⚙️
1/76-3/85	200, D (W123)	360 780		460 160 102 060	⚙️ ⚙️
12/67-12/76	200, D (W115)	360 850		460 160 102 060	⚙️ ⚙️
66-67	200, D (W110)	603 102		604 102 700 001	⚙️ ⚙️
65-70	200SEB (W110)	603 102		604 102 700 001	⚙️ ⚙️
12/85-93	200T, TD (Exc. 4-Matic) (W124)	361 11B	⚙️	102 811 102 812	⚙️ ⚙️
78-12/85	200T (S123)	360 780		102 805	⚙️

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear

MERCEDES BENZ (Continued)

220 MODELS

94-96	C220 (W202)	36A 110	36A 130 102 374		
12/67-12/76	220, D (W115)	360 850	460 160 102 060	⇄	
59-67	220B, SB, SEB (W110)	603 102	604 102 700 001	⇄	
1/76-3/85	220D (W123)	360 780	460 160 102 060	⇄	

230 MODELS

97-99	C230 (W202)	36A 110	36A 130 102 374		
8/73-11/76	230/4 (W115)	360 850	460 160 102 060	⇄	
12/67-12/76	230 (W114)	360 850	460 160 102 060	⇄	
98-99	230 Roadster (W170)	36A 420	36A 430		
1/76-3/85	230, E (W123)	360 780	460 160 102 060	⇄	
65-68	230, S (W111)	603 102	604 102 700 001	⇄	
3/77-12/85	230C, CE (W123)	360 780	460 160 102 060	⇄	
3/87-93	230CE (W124)	361 11B	361 201		802 834
85-93	230E (Exc. 4-Matic) (W124)	361 11B	361 201 102 809 102 810	⇄	802 834
78-12/85	230T, TE (S123)	360 780	102 805	⇄	
12/85-93	230TE (Exc. 4-Matic) (W124)	361 11B	102 811 102 812	⇄	802 834

240 MODELS

1/76-3/85	240D (W123)	360 780	460 160 102 060		
8/73-11/76	240D (W115)	360 850	460 160 102 060	⇄	
78-12/85	240TD (S123)	360 780	102 805	⇄	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear

MERCEDES BENZ (Continued)

250 MODELS

1/76-3/85	250 (W123)	360 780	460 160 102 060		
12/67-12/76	250, C, CE (W114)	360 850	460 160 102 060		
65-68	250 Convertible, S, SE Coupe (W108)	603 102	604 102 700 001		
85-93	250D (Exc. 4-Matic) (W124)	361 11B	361 201 102 809 102 810	802 834	
68-72	250S (W108)	603 102	604 102 700 001		
12/85-93	250TD (Exc. 4-Matic) (W124)	361 11B	102 811 102 812	802 834	

260 MODELS

86-93	260E w/ 4-Matic (W124)	100 717	361 201	802 834	
85-93	260E (Exc. 4-Matic) (W124)	361 11B	361 201 102 809 102 810	802 834	
9/85-91	260SE (W126)	360 900	102 216 460 161		

280 MODELS

94-99	C280 (W202)	36A 120	36A 130 102 374		
12/67-12/76	280, C, CE, E (W114)	360 850	460 160 102 060		
1/76-3/85	280, E (W123)	360 780	460 160 102 060		
3/77-12/85	280C, CE (W123)	360 780	460 160 102 060		
10/79-9/85	280S, SE, SEL (W126)	360 900	460 161 102 058		
9/72-80	280S, SE (W116)	360 900	460 161 102 058		
68-72	280S, SE (W108)	603 102	604 102 700 001		
73-76	280S, SE (W108)	360 900	460 161		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts		
		Front	Rear	Front	Rear	
MERCEDES BENZ (Continued)						
280 MODELS (Continued)						
74-9/85	280SL (W107)	360 852		460 161 102 058		
	280SLC to ch. #008365 (W107)	360 852		460 161 102 058		
	280SLC from ch. #008366 (W107)	360 850		460 160		
300 MODELS						
96-97	E300D (W210)	36A 170		36A 180 102 374		
1995	E300D Turbo (W124 E Class)	366 12C		36A 060 102 238		802 834
98-99	E300TD (W210)	36A 170		36A 180 102 406		
3/87-93	300CE (W124)	361 11B		361 201		802 834
86-93	300D, E w/ 4-Matic (W124)	100 717		361 201		802 834
85-93	300D, E (Exc. 4-Matic) (W124)	361 11B		361 201 102 809 102 810	 	802 834
1/76-3/85	300D (W123)	360 780		460 160 102 060		
92-93	300SD, SE w/ Adaptive Damping (W140)			102 311		
	300SD, SE w/o Adaptive Damping (W140)	36A 100		46A 020 102 309		
9/85-91	300SD, SDL, SE, SEL, TD (W126)	360 900		102 216 460 161		
10/79-9/85	300SD, TD (W126)	360 900		460 161 102 058		
9/72-80	300SD (W116)	360 900		460 161 102 058		
9/85-91	300SEL w/ Hydromats (W126)					
	Left Side	102 133		102 142		
	Right Side	102 134		102 142		
10/79-9/85	300SEL w/ Hydromats (W126)					
	Left Side	102 107		102 111		
	Right Side	102 108		102 111		
90-93	300SL w/ Optional Hydro-Pneumatic Susp. (W129)	102 344				
9/85-91	300SL (W107)			460 160		
86-93	300TD, TE w/ 4-Matic (W124)	100 717		102 811 102 812	 	802 834
	300TD Turbo, TE (Exc. 4-Matic) (W124)	361 11B		102 811 102 812	 	802 834
78-12/85	300TD (S123)	360 780		102 805		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear

MERCEDES BENZ (Continued)

320 MODELS

94-95	E320 Convertible (W124 E Class)	361 11B	✚	361 201 102 315	⇄	802 834	
	E320 Coupe, Sedan (W124 E Class)	366 12B	✚	36A 060 102 238	⇄	802 834	
96-99	E320 Sedan (W210)	36A 170		36A 180 102 406	⇄		
98-99	E320 Wagon (W210)	36A 170		102 420	⇄		
94-95	E320 Wagon (W124 E Class)	361 11B	✚	102 243	⇄	802 834	
94-99	S320 w/ Adaptive Damping (W140)			102 311	⇄		
	S320 w/o Adaptive Damping (W140)	36A 100		46A 020 102 309	⇄		
96-99	SL320 w/ Optional Hydro-Pneumatic Susp. (W129)	102 416	⇄	102 417	⇄		
1995	SL320 w/ Optional Hydro-Pneumatic Susp. (W129)	102 344	⇄	102 187	⇄		

350 MODELS

94-99	S350D Turbo w/ Adaptive Damping (W140)			102 311	⇄		
	S350D Turbo w/o Adaptive Damping (W140)	36A 100		46A 020 102 309	⇄		
88-91	350SDL (W126)	360 900		460 161			
9/72-80	350SE, SEL (W116)	360 900		460 161 102 058	⇄		
72-9/85	350SL, SLC (W107)	360 852		460 161 102 058	⇄		

380 MODELS

9/85-91	380SE (W126)	360 900		102 216 460 161	⇄		
10/79-9/85	380SE, SEC (W126)	360 900		460 161 102 058	⇄		
80-9/85	380SL (W107)	360 852		460 161 102 058	⇄		
	380SLC (W107)	360 850		460 161			

400 MODELS

92-93	400E w/o Self Leveling (W124)	366 12C	✚	361 201		802 834	
	400SE, SEL w/ Adaptive Damping (W140)			102 311	⇄	802 834	
	400SE, SEL w/o Adaptive Damping (W140)	36A 100		46A 020 102 309	⇄	802 834	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
MERCEDES BENZ (Continued)					
420 MODELS					
1997	E420 Sedan (W210)	36A 170	36A 180 102 406	⇄	
94-95	E420 (W124 E Class)	366 12C	361 201 102 315	⇄	802 834
94-99	S420 w/ Adaptive Damping (W140)		102 311	⇄	
	S420 w/o Adaptive Damping (W140)	36A 100	46A 020 102 309	⇄	
9/85-91	420SE, SEL (W126)	360 900	102 216 460 161	⇄	
81-91	420SEC (C126)	360 900	102 058	⇄	
9/85-91	420SL (W107)		460 160	⇄	
430 MODELS					
98-99	E430 Sedan (W210)	36A 170	36A 180 102 406	⇄	
450 MODELS					
3/73-80	450SE, SEL 6.9L (W116)	360 900	460 161 102 058	⇄	
	450SE, SEL 6.9L w/ Hydro-Pneumatic Suspension (W116)		102 058	⇄	
3/73-9/85	450SL (W107)	360 852	460 161 102 058	⇄	
78-9/85	450SLC 5.0L (W107)	360 850	460 160	⇄	
500 MODELS					
94-95	E500 (W124 E Class)	361 11B	102 277	⇄	802 834
94-99	S500, Sedan, Coupe w/ Adaptive Damping (W140)		102 311	⇄	
	S500, Sedan, Coupe w/o Adaptive Damping (W140)	36A 100	46A 020 102 309	⇄	
96-99	SL500 w/ Optional Hydro-Pneumatic Susp. (W129)	102 416	102 417	⇄	
1995	SL500 w/ Optional Hydro-Pneumatic Susp. (W129)	102 344	102 187	⇄	
92-93	500E w/ Self Leveling (W124)	366 12C	102 277	⇄	
	500E w/o Self Leveling (W124)	366 12C	361 201	⇄	
9/85-91	500SE, SEL (W126)	360 900	460 161 102 216	⇄	
10/79-9/85	500SE, SEL (W126)	360 900	460 161 102 058	⇄	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear

MERCEDES BENZ (Continued)

500 MODELS (Continued)

92-93	500SEC, SEL w/ Adaptive Damping (W140)			102 311			
	500SEC, SEL w/o Adaptive Damping (W140)	36A 100		46A 020			
				102 309			
81-91	500SEC (C126)	360 900		102 058			
9/85-91	500SEL w/ Hydromats (W126) Left Side	102 133		102 142			
		Right Side		102 142			
10/79-9/85	500SEL w/ Hydromats (W126) Left Side	102 107		102 111			
		Right Side		102 111			
90-93	500SL w/ Optional Hydro-Pneumatic Susp. (W129)	102 344		102 187			
9/85-91	500SL (W107)			460 160			
3/73-9/85	500SL (W107)	360 852		460 161			
				102 058			
80-9/85	500SLC (W107)	360 850		460 160			

560 MODELS

88-91	560SE, SEC, SEL (W126)	360 900		102 216			
9/85-87	560SE, SEC, SEL (W126)	360 900		102 058			
81-91	560SEC (C126)	360 900		102 058			
9/85-89	560SL (W107)	360 852		460 161			

600 MODELS

94-99	S600, Sedan, Coupe w/ Adaptive Damping (W140)			102 311			
	S600 Sedan w/o Adaptive Damping (W140)	36A 100		102 309			
94-97	S600 Coupe w/o Adaptive Damping (W140)	36A 100		46A 020			
				102 309			
96-99	SL600 w/ Optional Hydro-Pneumatic Susp. (W129)	102 416		102 417			
1995	SL600 w/ Optional Hydro-Pneumatic Susp. (W129)	102 344		102 417			
93-94	SL600, 600SL w/ Optional Hydro-Pneumatic Susp. (W129)	102 344					
92-93	600SEC, SEL w/ Adaptive Damping (W140)			102 311			
	600SEC, SEL w/o Adaptive Damping (W140)	36A 100		46A 020			
				102 309			

MERCURY

BOBCAT

75-80	All (Exc. Station Wagon)	030 823		030 828			
	Station Wagon	030 823					

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
MERCURY (Continued)					
CAPRI					
91-94	All	030 002	030 626		802 724
83-86	All	030 002	030 232	802 728	
79-82	All	030 002	030 232		
71-78	All	030 733			
COMET					
71-77	All	030 270	030 815		
COUGAR, XR-7					
92-97	All (Exc. Elec. Adj. Susp.)	030 613	030 729		
89-97	All (Exc. Elec. Adj. Susp.)			802 734	
89-91	All (Exc. Elec. Adj. Susp.)	030 613	030 728		
87-88	All (Exc. Turbo and V8)	030 002	030 233		
83-86	All	030 016	030 233		
81-82	All (Exc. XR-7)	030 016	030 232	802 728	
80-82	All	030 016	030 233		
74-79	All	030 229	030 232		
71-73	All	030 705	030 271		
67-70	All	030 270	030 271		
80-88	XR-7			802 732	
FULL SIZE					
65-82	All	030 229	030 232		
61-64	All	030 831	030 834		
59-60	All	030 831	030 271		
57-58	All	030 831			
52-56	All	030 832			
49-51	All	030 832			
83-00	Grand Marquis, Colony Park, Station Wagon	030 229	030 232		
83-86	Marquis	030 002	030 232	802 728	
LYNX, LN7					
1983	All (Mfg. after Feb/83)	030 652	030 650	802 760	802 733
81-83	All (Mfg. before Feb/83)	030 649	030 650	802 760	802 733
85-87	Lynx (Mfg. after March/85)	030 006	030 650	802 837 802 711(*)	802 733
84-85	Lynx (Mfg. before March/85)	030 652	030 650	802 760	802 733

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
MERCURY (Continued)					
MONARCH					
75-80	All	030 705	030 815		
MOUNTAINEER					
97-00	All (Exc. Elec. Adj. Susp.)	030 788	030 789		
MONTEGO					
72-76	All	030 229	030 232		
68-71	All (Exc. Station Wagon)	030 802	030 271		
	Station Wagon	030 802	030 232		
MYSTIQUE					
95-00	All	030 643	030 644	802 772	802 775
SABLE					
96-00	All (Exc. Wagon and SHO)	030 670	030 671	802 774	802 750
91-95	All (Exc. Station Wagon Rear)			802 712(*)	802 750
86-95	All (Exc. Station Wagon)	030 630	030 605		
86-90	All (Exc. Station Wagon Rear)			802 712(*)	802 705
96-00	Station Wagon	030 670	030 854		
86-95	Station Wagon	030 630	030 269		
TOPAZ					
84-94	All			802 837 802 711(*)	802 709
84-85	All (Mfg. before March/85)	030 014	030 007		
85-94	2WD (Mfg. after March/85)	030 006	030 007		
87-91	4WD	030 006	030 656		
TRACER					
91-00	All (Exc. 4WD & ABS)				
	Left Side	030 619	030 621	802 723	802 725
	Right Side	030 620	030 622	802 723	802 725
87-90	All	030 651	030 608	802 720	802 724
91-95	4WD				
	Left Side	030 619			
	Right Side	030 620			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
MERCURY (Continued)					
VILLAGER					
93-00	All (Incl. ABS)				
	Left Side	030 673	030 752	802 810	
	Right Side	030 674	030 752	802 810	
ZEPHYR					
82-83	All (Exc. Police Package)			802 728	
78-83	All	030 002	030 232		
81-82	All w/ TRX Suspension			802 728	
MERKUR					
87-90	Scorpio	32A 48F	273 79F		
85-89	XR4Ti	324 95F	36A 140		
83-84	XR4Ti	321 38F	36A 140		
MITSUBISHI					
CORDIA					
83-88	All	030 607	030 274		
DIAMANTE					
92-96	All (Exc. Electric Mount)			802 831(*)	
ECLIPSE					
90-94	All			802 731	802 806
95-99	AWD	030 668		802 806	802 806
91-94	AWD & 4WD	030 627	030 744		
1990	AWD & 4WD	030 614	030 744		
95-99	FWD	030 668	030 748		
91-94	FWD	030 627	030 749		
1990	FWD	030 614			
GALANT					
94-00	All	030 669	030 748	802 806	802 806
85-98	All (Exc. Automatic Leveling System)				802 806
89-93	All (Exc. AWD)	207 34A	205 34A		
85-88	All (Exc. Elec. Adj. Susp. & ABS)	030 607	205 25A		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
MITSUBISHI (Continued)					
GALANT (Continued)					
89-93	AWD	030 627	030 744		
MIRAGE					
93-96	All (Mfg. before 4/30/96)	030 672	030 746	802 767(*)	802 806
89-92	All	030 616	030 743	802 745	802 806
87-88	All	030 612	030 274		
85-86	All	030 654	030 274		
MONTERO					
92-00	All (Exc. Air Suspension)	206 51A	206 50A		
89-91	All w/ 6 cyl.	030 255	030 771		
85-89	All w/ 4 cyl.	030 255	030 262		
83-84	All	030 255	030 262		
PICKUP					
83-95	2WD	030 266	030 222		
	4WD	030 255	030 222		
PRECIS					
90-93	All	207 18A	030 274		
87-89	All w/ Rebuildable OE Front Struts	203 36A	030 274	802 749(*)	
STARION					
87-89	All (Exc. Adjustable Suspension)	030 737	030 606	802 766(*)	802 765
83-86	All (Exc. ESI)	030 738	030 606	802 766(*)	802 765
TREDIA					
83-88	All	030 607	030 274		
VAN / WAGON					
87-89	All	206 31A	030 222		
92-96	Expo	208 68A	206 61A		
3000GT					
91-96	All w/ 2WD (Exc. Elec. Adj. Susp.)			802 809(*)	802 806

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
NISSAN					
ALTIMA					
93-99	All Left Side Right Side	208 19A 208 20A	208 21A 208 22A	802 826 802 826	
AXXESS					
90-94	All XE Wagon w/ FWD Left Side Right Side	207 32A 207 33A	203 21A 203 21A		
FRONTIER					
98-99	2WD	030 706	030 222		
2000	4WD w/ Crew Cab	206 73A	030 262		
98-99	4WD (Exc. Crew Cab)	030 706	030 262		
MAXIMA					
95-00	All (Exc. Elect. Adj. Susp.) Left Side Right Side	208 71A 208 72A	205 31A 205 31A		
89-94	All (Exc. Elect. Adj. Susp.) Left Side Right Side	207 32A 207 33A	203 40A 203 40A		
86-88	All (Exc. Elect. Adj. Susp. & Station Wagon)	207 05A	203 21A		
85-88	All (Exc. Elect. Adj. Susp.)			802 813	
1985	All (Exc. Elect. Adj. Susp.)	207 10A	203 21A		
83-84	Wagon	203 25A	030 719		
NX1600, NX2000					
91-95	All Left Side Right Side	207 64A 207 64A	030 052 030 053		
PATHFINDER					
96-00	All Left Side Right Side	209 09A 209 10A	206 58A 206 58A		
87-95	All (Exc. Elect. Adj. Susp.)	206 31A	030 262		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
NISSAN (Continued)					
PICKUP					
69-81	All	030 236	206 05A		
86-96	2WD (Mfg. from Aug/86)	030 706	030 222		
82-86	2WD (Mfg. to July/86)	030 236	206 05A		
82-96	4WD	030 236	030 262		
PULSAR					
2/86-90	All	207 64A	207 65A		
82-1/86	All	207 44A	200 11A		
QUEST, VAN					
93-00	Quest (Incl. ABS) Left Side Right Side	030 673 030 674	030 752 030 752	802 810 802 810	
87-89	All	206 13A	206 14A		
SENTRA					
95-00	All B14 Platform Left Side Right Side	030 056 030 057	030 280 030 280	802 729(*) 802 729(*)	
93-95	All B13 Platform Left Side Right Side	030 054 030 055	030 052 030 053	802 729(*) 802 729(*)	
91-92	All (Exc. ABS) Left Side Right Side	207 64A 207 64A	030 052 030 053	802 729(*) 802 729(*)	
2/86-90	All (Exc. 4WD)	207 64A	207 65A		
82-1/86	All	207 44A	200 11A		
1990	XE 2Dr.	207 64A	207 65A		
STANZA, MULTI					
90-92	All Left Side Right Side	207 35A 207 36A	203 40A 203 40A	802 826 802 826	
87-89	All (Exc. Wagon, Van)	207 05A	203 21A	802 813	
85-86	All (Exc. Wagon, Van)	203 18A	203 19A		
82-84	All (Exc. Wagon, Van)	203 18A	203 19A		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
NISSAN (Continued)					
STANZA, MULTI (Continued)					
85-89	Wagon 2WD				
	Left Side	207 11A	200 12A		
	Right Side	207 12A	200 12A		
	Wagon, Van 4WD	207 17A			
XTERRA					
2000	All	206 73A	030 262		
200 MODELS					
85-88	All	203 32A	200 16A		
1984	All	203 32A	200 06A		
80-83	All	203 16A	200 06A		
76-79	All	203 50A	200 06A		
95-00	200SX				
	Left Side	030 056	030 280	802 729(*)	
	Right Side	030 057	030 280	802 729(*)	
210 MODELS					
79-82	All	203 16A	200 06A		
240, 260 MODELS					
89-94	240SX (Exc. Active Suspension)				
	Left Side	208 69A	205 19A		
	Right Side	208 70A	205 19A		
70-8/74	240/260Z (Exc. 2+2)	203 25A	203 26A		
9/74-78	260Z (Incl. 2+2)	203 25A	203 27A		
280 MODELS					
1983	All	203 25A	205 00A		
79-82	All	203 25A	205 01A		
9/74-78	All (Incl. 2+2)	203 25A	203 27A		
300 MODELS					
90-96	All (Exc. Turbo)				
	Left Side	205 16A	205 18A		
	Right Side	205 17A	205 18A		
87-89	All (Exc. Turbo)	203 38A	202 03A		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
NISSAN (Continued)					
300 MODELS (Continued)					
84-86	All (Exc. Turbo)	203 33A	202 03A		
410, 411 MODELS					
64-69	All	030 226	030 232		
510 MODELS					
78-81	Sedan	203 16A	200 06A		
1972	Sedan	203 52A	201 12A		
68-71	Sedan	203 51A	201 12A		
78-81	Wagon	203 16A	030 719		
72-73	Wagon	203 52A	030 273		
68-71	Wagon	203 51A	030 232		
610 MODELS					
72-76	Sedan	203 52A	201 12A		
710 MODELS					
73-77	Sedan	203 52A	030 273		
810 MODELS					
81-84	Sedan	203 25A	205 01A		
77-80	Sedan	203 50A	205 01A		
81-82	Wagon	203 25A	202 07A		
OLDSMOBILE					
ACHIEVA					
96-98	All				
	Left Side	030 692	030 732	802 779(*)	802 704
	Right Side	030 693	030 732	802 779(*)	802 704
92-98	All			802 719(**)	
92-94	All (Exc. FE3 & Elec. Adj. Susp.)				
	Left Side	030 683	030 231		
	Right Side	030 684	030 231		
1995	All (Exc. Elec. Adj. Susp.)				
	Left Side	030 683	030 732	802 736(*)	802 704
	Right Side	030 684	030 732	802 736(*)	802 704

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
OLDSMOBILE (Continued)					
ACHIEVA (Continued)					
92-94	All w/ FE3 Suspension				
	Left Side	030 685	030 231	802 736(*)	802 704
	Right Side	030 686	030 231	802 736(*)	802 704
ALERO					
99-00		TBA			
AURORA					
95-99	All			802 719(**)	
	All			802 803(*)	802 704
BRAVADA					
91-99	All	030 211	030 210		
CALAIS					
85-91	All w/ Non-Rebuildable OE Struts				
	Left Side	030 008	030 231	802 706(*)	802 704
	Right Side	030 009	030 231	802 706(*)	802 704
85-86	All w/ Rebuildable OE Struts	030 741	030 231		
CUTLASS, F-85, CIERA					
78-81	All	030 226	030 227		
73-77	All (Exc. 1975-77 F-85)	030 226	030 227		
68-72	All (Exc. Vista Cruiser)	030 226	030 227		
85-96	Ciera & Ciera Cruiser Station Wagon (Exc. Elec. Adj. Susp.)	030 003	030 240		
84-96	Ciera			802 735(*)	802 704
1984	Ciera & Ciera Cruiser Station Wagon (Exc. HD Suspension)	030 010	030 240		
	Ciera & Ciera Cruiser Station Wagon w/ HD Suspension	030 003	030 240		
82-83	Ciera	030 010	030 204		
90-97	Cutlass Supreme (Exc. HD Suspension)			802 823(*)	802 707(*)
	Cutlass Supreme w/ HD Suspension			802 824(*)	
88-97	Cutlass Supreme				802 707(*)
88-96	Cutlass Supreme (Incl. Convertible)	030 001	030 680		
88-89	Cutlass Classic	030 226	030 227		
	Cutlass Supreme (Exc. HD Suspension)			802 822(*)	802 707(*)
	Cutlass Supreme w/ HD Suspension			802 825(*)	802 707(*)

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
OLDSMOBILE (Continued)					
CUTLASS, F-85, CIERA (Continued)					
85-87	Cutlass Supreme, Cutlass Salon	030 226	030 227		
1984	Cutlass Supreme, Cutlass Calais	030 226	030 227		
82-83	Cutlass Supreme, Cutlass Calais, Cutlass Station Wagon	030 226	030 227		
75-77	F-85	030 226	030 821		
68-72	Vista Cruiser	030 226	030 232		
FIRENZA					
87-88	All				
	Left Side	030 008	030 231		
	Right Side	030 009	030 231		
82-88	All			802 706(*)	802 704
84-86	All w/ Non-Rebuildable OE Struts				
	Left Side	030 008	030 231		
	Right Side	030 009	030 231		
82-83	All	030 736	030 231		
FULL SIZE					
71-84	All (Exc. Station Wagon)	030 229	030 227		
91-99	Delta 88 w/ Optional OE Self Leveling System	030 682	030 687		
	Delta 88 w/ Standard Rear Suspension	030 682	030 679		
90-96	Delta 88			802 738(*)	
87-96	Delta 88 & 98			802 719(**)	
86-95	Delta 88				802 708
86-89	Delta 88			802 737(*)	
	Delta 88 w/ Optional OE Self Leveling System	030 676	030 687		
	Delta 88 w/ Standard Rear Suspension	030 676	030 679		
1985	Delta 88	030 229	030 227		
96-99	LSS	030 682	030 687	802 738(*)	802 708
	LSS w/ Conventional Type Replacement for Air Assist Rear Suspension	030 682	030 679		
77-91	Station Wagon (RWD)	030 229	030 227		
71-76	Station Wagon	030 229	030 227		
1990	88 Early Design (Front Struts w/ Spring Guard)	030 676	030 679		
	88 Late Design (Front Struts w/o Spring Guard)	030 682	030 679		
	88 w/ Optional OE Self Leveling System				
	Early Design (Front Struts w/ Spring Guard)	030 676	030 687		
	Late Design (Front Struts w/o Spring Guard)	030 682	030 687		
91-96	98			802 738(*)	
	98 Air Assist Rear Suspension (Std. Equipment)	030 682	030 687		
	Conv. Type Replacement for Air Assist Rear Susp.	030 682	030 679		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
OLDSMOBILE (Continued)					
FULL SIZE (Continued)					
85-96	98				802 708
85-90	98 Air Assist Rear Suspension (Std. Equipment)	030 676	030 687		
	Conv. Type Replacement for Air Assist Rear Susp.	030 676	030 679		
	98				802 737(*)
INTRIGUE					
97-00	All	208 61A	208 62A		
OMEGA					
1984	All w/ HD Suspension	030 003	030 240		
	All (Exc. HD Suspension)	030 010	030 240		
82-84	All				802 704
80-83	All	030 010	030 240		
73-79	All	030 226	030 821		
SILHOUETTE VAN					
97-00	All	208 61A	030 850		
90-96	All	030 003	030 799	802 735(*)	802 704
STARFIRE					
75-80	All	030 808	030 703		
TORONADO					
90-93	All	030 681	030 678		
86-92	All				802 778
90-91	All				802 756(*)
	All				802 719(**)
86-89	All	030 677	030 678		802 757(*)
79-85	All	030 702	030 981(***)		
71-78	All	030 810	030 227		
PEUGEOT					
77-8/85	504/505 Sedan from ch. #2181 357	270 94F	320 45F		
77-6/83	504 Wagon from ch. #2181 357	270 94F			
68-76	504 Sedan		320 45F		
85-93	505 Turbo from ch. #1887 752		320 45F		
	505 Turbo to ch. #1887 751	270 94F	320 45F		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
PEUGEOT (Continued)					
PEUGEOT (Continued)					
9/86-93	505 Sedan w/ ABS		320 45F		
9/85-93	505 Sedan w/o ABS	271 48F	320 45F		
	505 Wagon from ch. #1854 001	271 48F			
82-8/85	505 Wagon to ch. #1845 000	270 94F			
76-86	604		320 45F		
PLYMOUTH					
ACCLAIM (A BODY)					
89-95	All	030 005	030 228	802 703(*)	
ARROW					
76-81	All (Exc. Pickup)	030 735	030 818		
79-82	Pickup	030 266	030 222		
BARRACUDA					
70-74	All	030 816	030 812		
64-69	All	030 816	030 275		
BELVEDERE, GTX, SATELLITE, SEBRING					
73-74	All	030 701	030 812		
62-72	All	030 816	030 812		
BREEZE					
2000	All w/o Bracket	030 667	030 747	802 816	802 771
95-99	All	030 667	030 747	802 816	802 771
CARAVELLE (E BODY)					
86-88	All (Mfg. after Jan/86)	030 005	030 228	802 703(*)	
85-86	All (Mfg. to Jan/86)	030 015	030 228	802 702(*)	
CHAMP, COLT					
85-86	All (Exc. Vista Station Wagon)	030 654	030 274		
79-82	Champ Hatchback	030 734	030 274	802 749(*)	
93-95	Colt	030 672	030 746	802 767(*)	802 806
89-91	Colt-E 3Dr.	030 616	030 743		802 806

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
PLYMOUTH (Continued)					
CHAMP, COLT (Continued)					
87-88	Colt-E 3Dr.	030 612	☺ 030 274		
1984	Colt Hatchback w/ Sealed Front Struts		030 274		
83-84	Colt Hatchback (Exc. Models w/ Sealed Front Struts)	030 734	☺ 030 274		
88-89	Colt Station Wagon 2 & 4WD	030 612	☺ 030 274		
92-94	Colt Vista 2 & 4WD Wagon				802 806
84-91	Colt Vista Station Wagon 2WD	030 607	☺ 030 274		
92-94	Colt Vista Wagon			802 758	802 806
1992	Colt Vista Wagon	030 627	☺		
89-92	Hatchback			802 745	802 806
85-91	Vista Station Wagon 4WD	030 609	☺ 030 715		
CONQUEST					
87-89	All (Exc. Elec. Adj. Susp.)	030 737	☺ 030 606	☺ 802 766(*)	802 765
84-86	All (Exc. ESI)	030 738	☺ 030 606	☺ 802 766(*)	802 765
FURY					
77-78	All (Exc. Police Package)	030 701	030 268		
75-76	All	030 701	030 812		
1974	All	030 235	030 812		
70-72	All	030 813			
1973	Station Wagon	030 813	030 812		
GRAN FURY					
82-89	All	030 235	030 268		
80-81	All	030 701	030 268		
75-77	All	030 235	030 812		
HORIZON, TURISMO (L-BODY)					
78-90	All			802 700(*)	
81-89	All	030 011	☺ 030 745		
78-80	All	030 011	☺ 030 742		
1990	4Dr.	030 618	☺ 030 745		
LASER					
94-97	All	030 012	☺ 030 013		
89-94	All			802 731	802 806
92-94	2Dr. Hatchback w/ ABS	030 627	☺ 030 744		
89-93	2Dr. Hatchback (Exc. ABS)	030 614	☺ 030 749		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
PLYMOUTH (Continued)					
NEON					
94-99	All	030 012	030 013	802 762	802 769
RELIANT (K BODY)					
86-89	All (Mfg. after Jan/86)	030 004	030 228	802 703(*)	
84-86	All (Mfg. to Jan/86)	030 015	030 228	802 702(*)	
1983	All			802 701(*)	
81-83	All	030 011	030 228		
81-82	All			802 700(*)	
ROADRUNNER					
76-80	All	030 235	030 268		
73-75	All	030 701	030 812		
71-72	All	030 816	030 812		
68-70	All	030 816	030 812		
SAPORO					
81-83	All			802 761	
78-83	All	030 735			
SUNDANCE (P BODY)					
86-94	All (Mfg. after Jan/86)	030 005	030 228	802 703(*)	
TRAIL DUSTER					
81-83	2WD	030 203	030 244		
76-83	4WD	030 241	030 249		
75-80	2WD	030 203	030 244		
74-75	4WD	030 241	030 244		
VALIANT, DUSTER, SCAMP					
60-76	All	030 816	030 275		
VOLARE					
76-80	All	030 235	030 268		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear

PLYMOUTH (Continued)

VOYAGER (S BODY)

96-00	All w/ Self Leveling	030 645	⬇️	030 051	⬆️		
	All	030 645	⬇️	030 791		802 770	
74-80	PB-100	030 203		030 207			
81-83	PB-150	030 203		030 207			
74-78	PB-200, PB-300 (Exc. PB-300 w/ 4000 lb Front Axle)	030 203		030 207			
81-83	PB-250, PB-350 (Exc. PB-350 w/ 4000 lb Front Axle)	030 203		030 207			
74-80	PB-300 w/ 4000 lb Front Axle	030 245		030 207			
81-83	PB-350 w/ 4000 lb Front Axle	030 245		030 207			
86-95	Voyager Van (Incl. AWD)	030 004	⬇️	030 213		802 703(*)	
84-86	Voyager Van (Mfg. to Jan/86)	030 601	⬇️	030 213		802 702(*)	

PONTIAC

ASTRE

75-77	All	030 808		030 703			
-------	-----	---------	--	---------	--	--	--

BONNEVILLE

91-99	All w/ Optional OE Self-Leveling System	030 682	⬇️	030 687	⬆️		
	All w/ Standard Rear Suspension	030 682	⬇️	030 679	⬆️		
90-96	All					802 738(*)	
1990	All w/ Optional OE Self Leveling System						
	Early Design Front Struts w/ Spring Guard	030 676	⬇️	030 687	⬆️		
	Late Design Front Struts w/o Spring Guard	030 682	⬇️	030 687	⬆️		
87-95	All						802 708
1990	All w/ Standard Rear Suspension						
	Early Design Front Struts w/ Spring Guard	030 676	⬇️	030 679	⬆️		
	Late Design Front Struts w/o Spring Guard	030 682	⬇️	030 679	⬆️		
87-89	All w/ Standard Rear Suspension	030 676	⬇️	030 679	⬆️	802 737(*)	
	All w/ Optional OE Self Leveling System	030 676	⬇️	030 687	⬆️	802 737(*)	
82-86	All	030 226		030 227			

FIERO

1988	All	030 711		030 617	⬇️		
84-87	All	030 724		030 602	⬇️		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
PONTIAC (Continued)					
FIREBIRD, TRANS AM					
93-00	All (Insulator Only)			802 804	
	All				
	Left Side	030 750	030 230	802 801	
	Right Side	030 750	030 230	802 802	
82-92	All				
	Left Side	030 675	030 230	802 715(*)	
	Right Side	030 675	030 230	802 716(*)	
70-81	All	030 229	030 700		
FIREFLY					
89-91	All	030 662	030 660	802 752	802 754
87-88	All	030 657			
85-86	All	030 657	030 708		
FULL SIZE					
77-81	All (Exc. Station Wagon)	030 229	030 227		
83-86	Parisienne Sedan	030 229	030 227		
83-89	Station Wagon	030 229	030 227		
71-81	Station Wagon	030 229	030 227		
GRAN PRIX					
97-99	All	208 61A	208 62A		
90-96	All w/ HD Suspension			802 824(*)	
	All (Exc. HD Suspension)			802 823(*)	
88-96	All	030 001	030 680		802 707(*)
88-89	All w/ HD Suspension			802 825(*)	
	All (Exc. HD Suspension)			802 822(*)	
69-87	All	030 226	030 227		
PHOENIX					
1984	All w/ HD Suspension	030 003	030 240		
	All (Exc. HD Suspension)	030 010	030 240		
82-84	All				802 704
80-83	All	030 010	030 240		
77-79	All	030 226	030 821		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
PONTIAC (Continued)					
SUNBIRD, 2000, J2000					
82-94	All				802 704
92-94	All w/ Sport Suspension			802 717(*)	
84-94	All w/ Non-Rebuildable OE Struts				
	Left Side	030 008	☛ 030 231		
	Right Side	030 009	☛ 030 231		
82-91	All			802 706(*)	
84-86	All w/ Rebuildable OE Struts	030 741	☛ 030 231		
82-83	All	030 736	☛ 030 231		
76-80	All	030 808	☛ 030 703		
SUNFIRE					
95-00	All	030 646	☛ 030 688	☛ 802 779(*)	802 805
TEMPEST, LEMANS, GRAND AM, GTO					
85-91	All			802 706(*)	802 704
68-81	All (Exc. 1974 GTO)	030 226	☛ 030 227		
96-98	Grand Am				
	Left Side	030 692	☛ 030 732	802 779(*)	802 704
	Right Side	030 693	☛ 030 732	802 779(*)	802 704
1995	Grand Am (Exc. Elec. Adj. Susp.)				
	Left Side	030 683	☛ 030 732		802 704
	Right Side	030 684	☛ 030 732		802 704
92-94	Grand Am			802 736(*)	
	Grand Am w/ FE3 Suspension				
	Left Side	030 685	☛ 030 231		802 704
	Right Side	030 686	☛ 030 231		802 704
	Grand Am (Exc. FE3 & Elec. Adj. Susp.)				
	Left Side	030 683	☛ 030 231		802 704
	Right Side	030 684	☛ 030 231		802 704
87-91	Grand Am				
	Left Side	030 008	☛ 030 231		
	Right Side	030 009	☛ 030 231		
85-86	Grand Am w/ Non-Rebuildable OE Struts				
	Left Side	030 008	☛ 030 231		
	Right Side	030 009	☛ 030 231		
	Grand Am w/ Rebuildable OE Struts	030 741	☛ 030 231		
1974	GTO	030 226	☛ 030 821		
90-93	LeMans	030 740	☛ 030 716	802 755	
88-89	LeMans	030 740	☛ 030 718	802 755	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
PONTIAC (Continued)					
TRANS SPORT VAN					
97-00	All	208 61A	☺ 030 850		
90-96	All (Exc. Auto. Air Leveling)	030 003	☺ 030 799	802 735(*)	802 704
VENTURA II					
74-77	All	030 226	030 227		
1973	All w/ HD Suspension	030 226	030 227		
	All (Exc. HD Suspension)	030 226	030 821		
71-72	All w/ Multi-Leaf Rear Springs	030 226	030 227		
	All w/ Single Leaf Rear Springs	030 226	030 821		
1000, T1000, ACADIAN					
81-87	All	030 272	030 273		
6000					
90-91	All			802 735(*)	
85-91	All (Exc. AWD)	030 003	☺ 030 240		
84-91	All (Exc. Self Leveling System)				802 704
1984	All (Exc. HD Suspension, STE)	030 010	☺ 030 240		
	All w/ HD Suspension (Exc. STE)	030 003	☺ 030 240		
82-83	All	030 010	☺ 030 240		
84-88	STE (Exc. AWD)	030 003			
88-91	6000, 6000 STE w/ AWD	030 003			
PORSCHE					
911					
91-94	911 Carrera 2 Turbo, RS Series	Left Side	366 67G	☺	
		Right Side	366 68G	☺	
	911 Carrera 4 Turbo, RS Series	Left Side	366 67H	☺	
		Right Side	366 68H	☺	
8/88-94	911 Carrera 2 (Exc. Turbo, RS Series)	Left Side	366 67G	☺	321 66C
		Right Side	366 68G	☺	321 66C
8/88-8/90	911 Carrera 4 (Exc. Turbo, RS Series)	Left Side	366 67H	☺	321 66C
		Right Side	366 68H	☺	321 66C

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
PORSCHE (Continued)					
911 (Continued)					
4/85-7/88	911 Carrera (H Series)	323 36F	322 50F		
6/75-3/85	911TC, SC, Carrera (Exc. Turbo)	323 88F	322 50F		
6/71-76	911, E, T	323 88F	322 50F		
912					
1976	912E	323 88F	322 50F		
924					
85-9/87	924 S 2.5L	278 91F	271 53F		
80-7/84	924 Carrera GT	278 91F	36A 330		
11/78-7/84	924 Turbo	278 91F	36A 330		
11/75-84	924	278 91F	36A 330		
928					
8/85-95	928, 928S w/ Boge Shocks	324 27B	324 28B		
944					
7/89-91	944, S2 w/ Standard Suspension		271 53F		
9/86-6/89	944, S		271 53F		
8/84-6/89	944 Turbo				
	Left Side	100 665	271 53F		
	Right Side	100 666	271 53F		
8/84-8/86	944 (Exc. Turbo)	278 91F	271 53F		
81-7/84	944 (Exc. Turbo)	278 91F	36A 330		
968					
92-95	968 Coupe, Cabrio 3.0L		105 787		
ROVER					
LANDROVER					
83-92	Landrover		000 670		
70-92	Range Rover w/ 100" Wheel Base w/o Sway Bar		000 510		
3500					
80-81	3500		600 921		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear

SAAB

99

78-8/84	Heavy Duty		360 821		
---------	------------	--	---------	--	--

900

94-98	900 Convertible (Incl. Turbo)	32B 57F	↓	27B 06F		
	900 Coupe, Sedan (Incl. Turbo)	32B 56F	↓	27B 05F		
2/84-93	900 Turbo w/ Sway Bar	112 102		106 003		
	900 Turbo Sport w/ Sway Bar	112 103		106 003		
78-93	900 Turbo	360 811		360 821		
	900 (Exc. Turbo)	360 811		360 821		

9000

87-96	9000i 16V, Turbo 16V	32B 53F	↓	361 870 601 680	↑		
6/84-87	9000i 16V, Turbo 16V	32A 67F	↓	361 870 601 680	↑		

Note: 32-372-F has a tapered section below the threads

SATURN

91-98	All	030 665	↓	030 664	↓	802 746(*)	802 747
-------	-----	---------	---	---------	---	------------	---------

STERLING

87-91	825, 827 Left Side Right Side			601 250 601 260	↑ ↑		
-------	-------------------------------------	--	--	--------------------	--------	--	--

SUBARU (EXC. VEHICLES W/ AIR SUSPENSION)

DL, GL 2WD

85-90	DL, GL Wagon Left Side	207 58A	↓	205 13A		
	Right Side	207 59A	↓	205 13A		
	DL, GL 2Dr. Hatchback	207 49A	↓	202 04A		
	DL, GL, 3 & 4Dr. Sedan Left Side	207 58A	↓	205 08A		
	Right Side	207 59A	↓	205 08A		
83-84	DL, GL	207 49A	↓	202 04A		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
SUBARU (EXC. VEHICLES W/ AIR SUSPENSION) (Continued)					
DL, GL 2WD (Continued)					
80-82	DL, GL	203 03A		202 04A	
DL, GL, BRAT 4WD					
82-84	All	207 51A		202 04A	
80-81	DL, GL (Exc. 1980-81 Brat & Vehicles w/ OE Strut No. 7210032063)	203 02A		202 04A	
85-88	GL Brat	207 51A		202 04A	
85-89	GL 2Dr. Hatchback	207 51A		202 04A	
8/86-89	GL 3Dr.				
	Left Side	207 86A		205 12A	
	Right Side	207 87A		205 12A	
	GL 4Dr.				
85-87	Sedan & Station Wagon (Exc. Air Suspension)	Left Side		205 11A	
		Right Side		205 11A	
7/86-89	Station Wagon (Exc. Air Strut)	Left Side		205 13A	
		Right Side		205 13A	
LEGACY					
92-94	2WD (Exc. Air Suspension)	Left Side		208 57A	
		Right Side		208 58A	
90-91	2WD	Left Side		208 55A	
		Right Side		208 56A	
95-99	4WD	Left Side		209 03A	
		Right Side		209 04A	
92-94	4WD (Exc. Air Suspension)	Left Side		208 53A	
		Right Side		208 54A	
90-91	4WD (Exc. Air Suspension)	Left Side		208 51A	
		Right Side		208 52A	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
SUBARU (EXC. VEHICLES W/ AIR SUSPENSION) (Continued)					
LEGACY OUTBACK					
97-99	All				
	Left Side	209 05A	⬇	209 07A	⬇
	Right Side	209 06A	⬇	209 08A	⬇
1996	All				
	Left Side	209 05A	⬇		
	Right Side	209 06A	⬇		
LOYALE					
90-94	RS Coupe 4WD				
	Left Side	207 86A	⬇	205 12A	
	Right Side	207 87A	⬇	205 12A	
	Wagon 2WD				
	Left Side	207 58A	⬇	205 13A	
	Right Side	207 59A	⬇	205 13A	
	Wagon 4WD				
	Left Side	207 86A	⬇	205 13A	
	Right Side	207 87A	⬇	205 13A	
	4Dr. Sedan 2WD & Coupe				
	Left Side	207 58A	⬇	205 08A	
	Right Side	207 59A	⬇	205 08A	
4Dr. Sedan 4WD					
Left Side	207 86A	⬇	205 11A		
Right Side	207 87A	⬇	205 11A		
XT					
85-91	XT 2WD (Exc. XT6 & Air Suspension)				
	Left Side	207 60A	⬇	205 08A	
	Right Side	207 61A	⬇	205 08A	
	XT6 (Exc. Air Suspension)			205 08A	
SUZUKI					
FORSA					
85-88	All	030 657	⬇	030 710	⬇
SAMURAI					
86-95	JL, JX	200 18A		200 19A	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
SUZUKI (Continued)					
SIDEKICK					
96-00	ABS		030 801		
89-00	All (Exc. ABS)				
	Left Side	030 628	030 801	802 753	
	Right Side	030 629	030 801	802 753	
SWIFT					
89-95	All	030 662	030 660	802 752	802 754
X-90					
96-98	All		030 866		
TOYOTA					
AVALON					
95-00	All				
	Left Side	030 022	030 024	802 828(*)	802 829
	Right Side	030 021	030 023	802 828(*)	802 829
	All w/ Rebuildable OE Struts	203 53A			
CAMRY					
95-00	All w/ Sealed Front Struts				
	Left Side	030 022	030 024		
	Right Side	030 021	030 023		
92-96	All				802 829
92-94	All			802 828(*)	
	All w/ Rebuildable Front Struts (Exc. All Trac)	203 47A	203 48A		
	All w/ Sealed Front Struts (Exc. All Trac)				
	Left Side	208 28A	030 024		
	Right Side	208 29A	030 023		
87-91	All (Exc. ABS & All-Trac)				802 820
	All w/ Rebuildable Front Struts (Exc. Wagon & All Trac)	203 39A	207 21A		
	All w/ Sealed Front Struts (Exc. Wagon & All Trac)	207 22A	207 21A		
	All Trac	207 22A			
83-86	All	203 24A	030 658	802 710(*)	802 748
87-91	Sedan SV25 All Trac (Exc. ABS)			802 718(*)	802 748
	Wagon w/ Rebuildable Front Struts	203 39A	207 20A		
	Wagon w/ Sealed Front Struts	207 22A	207 20A		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
TOYOTA (Continued)					
CARINA					
72-73	All	203 31A	201 12A		
CELICA					
90-91	All (Exc. ABS & 4WD)	203 42A	207 31A		
88-89	All	203 39A	207 16A		802 748
86-87	All (Exc. All Trac)	203 23A	207 06A		802 748
82-85	All (Exc. GTS)	203 22A	201 12A		
10/75-81	All	203 22A	201 12A		
7/73-9/75	All	203 31A	201 12A		
82-85	GTS	203 22A	202 02A		
92-93	ST, GT	203 42A	207 31A		
90-91	4WD	203 42A			
COROLLA					
93-00	All Left Side Right Side	030 631 030 632	030 633 030 634		
88-96	All Left Side Right Side				802 739 802 740
89-92	All (Exc. All Trac)	030 615	030 611		
88-92	All			802 718(*)	
1988	All (Exc. All Trac & FX-16)	030 615	030 611		
87-88	All w/ Rebuildable Front Struts	203 23A	030 658		
	All w/ Sealed Front Struts	030 653	030 658		
1987	All (Exc. FX-16 w/ Rebuildable Front Struts)	203 10A	030 658		
	All (Exc. FX-16 w/ Sealed Front Struts)	030 653	030 658		
1986	All w/ Rebuildable Front Struts	203 10A	030 658		
	All w/ Sealed Front Struts	030 653	030 658		
8/74-79	All (Exc. Wagon & 1200)	203 22A	030 273		
84-87	Coupe				802 748
84-88	FWD Sedan & Hatchback			802 710(*)	802 748
84-85	FWD Diesel	203 23A	030 658		
	FWD w/ Rebuildable Front Struts (Exc. Diesel)	203 10A	030 658		
	FWD w/ Sealed Front Struts (Exc. Diesel)	030 653	030 658		
87-88	FX-16, FX			802 710(*)	
84-87	RWD	203 22A	201 12A		
80-83	RWD (Exc. Wagon)	203 22A	201 12A		
80-81	Sedan & Wagon			802 817(*)	
4/73-7/74	SR5	203 31A			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
TOYOTA (Continued)					
COROLLA (Continued)					
88-91	Trac Wagon	203 41A	201 12A		
8/74-83	Wagon	203 22A	201 11A		
8/74-79	1200		030 273		
CORONA					
79-82	All (Exc. Wagon)	030 255	201 11A		
8/73-78	All (Exc. Wagon)	030 226	201 12A		
64-7/73	All (Exc. Wagon)	030 226	030 232		
72-76	MKII	030 226	030 719		
79-81	Wagon	030 255	030 273		
8/73-78	Wagon	030 226	030 719		
CRESSIDA					
89-92	All (Exc. Elect. Adj. Suspension)	203 30A	205 26A		
85-92	All			802 832	802 842
81-88	All (Exc. Wagon)	203 30A	200 08A		
78-80	All (Exc. Wagon)	030 255	200 08A		
81-88	Wagon	203 30A	201 11A		
78-80	Wagon	030 255	030 273		
LAND CRUISER					
75-83	All (Mfg. from Jan/75, exc. Station Wagon)	030 752	030 262		
60-74	All (Mfg. to Dec/74, exc. Station Wagon)	030 752			
91-97	Land Cruiser	206 25A	206 26A		
88-90	Station Wagon	200 22A	206 39A		
80-87	Station Wagon	200 22A	030 262		
69-79	Station Wagon	030 262	030 232		
MR2					
92-95	All	203 45A	203 46A		
87-90	All	203 13A	203 35A		
85-86	All	203 13A	203 14A		
PASEO					
92-95	All	208 06A	208 03A		802 827

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
TOYOTA (Continued)					
PICKUP - 1/2 TON					
70-78	All	030 209	030 222		
85-95	2WD	206 30A	030 222		
79-84	2WD	030 209	030 222		
86-95	4WD (Exc. Lift Kit)	206 03A	206 07A		
79-83	4WD w/ 2-3" Lift Kit	206 74A	030 760		
84-85	4WD (Exc. Lift Kit)	206 09A	206 07A		
79-83	4WD (Exc. Lift Kit)	206 09A	030 262		
PICKUP - 1 TON					
85-92	2WD	206 30A	030 262		
PREVIA					
90-97	All (Incl. All Trac)				
	Left Side	207 97A	206 27A		
	Right Side	207 98A	206 27A		
RAV4					
96-00	2WD, 4WD (Exc. L Models)		206 76A		
	2WD, 4WD (L Models Only)		206 75A		
SIENNA					
98-00	All				
	Left Side	209 11A	206 77A		
	Right Side	209 12A	206 77A		
STARLET					
81-84	All	203 08A	200 08A	802 717(*)	
SUPRA					
86-93	All			802 841	802 840
3/86-91	All	205 24A	205 21A		
84-2/86	All	203 22A	202 02A		
82-86	All			802 832	
82-83	All	203 31A	202 02A		
78-81	All	203 22A	201 12A		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model		Sachs <i>Super Gas</i>		Strut Mounts	
			Front	Rear	Front	Rear
TOYOTA (Continued)						
T-100						
93-99	2WD	206 30A	206 42A			
	4WD	206 03A	206 40A			
TACOMA						
95-00	2WD	206 52A	206 48A			
	4WD	205 30A	206 07A			
TERCEL						
91-94	All	208 06A	208 03A			
83-86	All			802 818	802 748	
	All (Exc. Wagon)	203 11A	030 658			
80-82	AL1, AL2	203 09A	202 06A	802 817(*)		
87-90	Sedan & Hatchback	203 00A	205 10A	802 819		
87-88	Station Wagon			802 818	802 748	
83-88	Wagon 2WD	203 11A	030 658			
	Wagon 4WD	203 12A	201 12A			
TUNDRA						
2000	All		206 78A			
VAN/WAGON						
84-88	All w/ Rear Leaf Springs	206 28A	030 222			
84-86	All w/ Rear Coil Springs	206 28A	206 04A			
87-89	2WD w/ Rear Coil Springs	206 28A	206 04A			
	4WD	206 12A	206 10A			
4-RUNNER						
96-00	All	205 30A	206 60A			
90-95	All	206 18A	206 19A			
86-89	All	206 03A	206 07A			
1985	All	206 09A	206 07A			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
VOLKSWAGEN					
AIR COOLED					
5/75-79	Type I, Super Beetle	203 44A			
5/67-77	Type I, Beetle, Karmann Ghia w/ Dbl. U-Joint Axle	201 09A	201 08A		
8/73-4/75	Type I, Super Beetle	203 44A	201 08A		
8/70-7/73	Type I, Super Beetle	203 43A	201 08A		
8/65-67	Type I, Beetle, Karmann Ghia w/ Swing Axle	201 09A			
10/63-65	Type I, Beetle, Karmann Ghia	201 08A	201 08A		
65-5/67	Type II	201 08A	201 08A		
3/53-66	Type II		916 002		
62-7/67	Type III, 1500, 1600 Sedan	201 08A	201 08A		
6/72-7/73	Type IV, 412		708 332		
8/67-73	Variant, Ghia	201 08A	201 08A		
BEETLE (NEW)					
1/98-00	All	32E 140	27C 08F		
CABRIO					
95-00	All	32A 69F	274 15F	802 713(*)	802 821
CABRIOLET					
85-93	Cabriolet (Rabbit)	272 29F	278 33F		
4/79-84	Convertible (Rabbit)	272 29F	278 33F		
CORRADO					
90-94	All (Exc. V6)			802 814(*)	
90-96	All				802 821
90-91	All 4 cyl. (Exc. Sealed Strut)	328 10F	275 28F		
90-94	All 4 cyl. w/ Sealed Strut	32A 70F	275 28F		
92-94	All 6 cyl.	32A 69F	275 28F		
DASHER					
75-81	All			802 713(*)	
10/80-81	Sedan	328 46F	270 36F		
9/77-9/80	Wagon		101 393		
10/80-81	Wagon	328 46F			

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
VOLKSWAGEN (Continued)					
EUROVAN					
1996	All		310 09B		
93-95	All from ch. #70P0200001	271 70A	310 09B		
	All to ch. #70P0200000	271 70A	310 09A		
FOX					
87-93	All (Exc. Wagon)	203 29A	205 02A	802 815(*)	
90-93	Wagon			802 815(*)	
88-93	Wagon	203 29A	205 27A		
GOLF II					
90-92	All w/ Sealed Struts (Exc. VR6 GTI)	27A 58F	274 15F		
85-90	All w/ Rebuildable Struts (Exc. GTI)	274 67F	274 15F		
90-92	GTI w/ Sealed Struts	27A 58F	275 28F		
85-90	GTI w/ Rebuildable Struts (Incl. 16V)	274 67F	275 28F		
85-92	Syncro w/ Rebuildable Struts	274 67F			
	Syncro w/ Sealed Struts	27A 58F			
GOLF III					
97-99	All w/ Sealed Struts (Exc. VR6 & GTI)	32B 66F	274 15F		
93-97	All			802 814(*)	802 821
93-96	All w/ Sealed Struts (Exc. VR6 & GTI)	27A 58F	274 15F		
96-97	Diesel, Trek	32B 66F	274 15F		
93-99	GTI w/ Sealed Struts	27A 58F	275 28F		
95-99	VR6	32A 69F	275 28F		
GOLF IV					
1/99-00	All (Incl. Sport Suspension)	32E 140	27C 08F		
JETTA I					
80-84	All			802 713(*)	802 821
79-1/84	All	272 29F	278 33F		
JETTA II					
90-92	All w/ Sealed Struts (Exc. VR6 & GLI)	27A 58F	274 15F		
85-92	All				802 821
	All w/ Rebuildable Struts			802 814(*)	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
VOLKSWAGEN (Continued)					
JETTA II (Continued)					
85-90	All w/ Rebuildable Struts (Exc. GLI)	274 67F	↓	274 15F	
90-92	GLI, 16V w/ Sealed Struts	27A 58F	↓	275 28F	
86-90	GLI (Incl. 16V w/ Rebuildable Struts)	274 67F	↓	275 28F	
JETTA III					
97-98	All w/ Sealed Struts (Exc. VR6 & GLI)	32B 66F	↓	274 15F	
93-97	All				802 814(*) 802 821
93-96	All w/ Sealed Struts (Exc. VR6 & GLI)	27A 58F	↓	274 15F	
93-97	GLI, 16V w/ Sealed Struts	27A 58F	↓	275 28F	
95-99	VR6 from ch. #1H-S-087-774	32A 69F	↓	275 28F	
94-95	VR6 to ch. #1H-S-087-773	32A 75F	↓	275 28F	
JETTA IV					
10/98-00	All (Incl. Sport Suspension)	32E 140	↓	27C 08F	
PASSAT					
98-00	All 1.8L, 1.9L Diesel, 2.8L 30V	330 86F		27C 11F 60A 060	↑
93-97	All (Exc. Diesel, VR6)	32A 75F	↓	279 82F	
90-96	All (Exc. VR6)				802 814(*)
90-92	All w/ Sealed Struts (Exc. VR6)	32A 70F	↓	279 82F	
4/88-90	Sedan w/ Rebuildable Struts 2.0L 16V	328 10F	↓	279 82F 601 820	↑
93-97	VR6	32A 75F	↓	279 82F	
QUANTUM					
81-88	All				802 830(*)
5/83-3/88	Sedan	328 46F	↓	273 10F 601 340	↑
82-4/83	Sedan	328 46F	↓	270 36F	
85-3/88	Wagon Syncro	328 46F	↓		
5/83-3/88	Wagon	328 46F	↓	270 36F 600 900	↑
82-4/83	Wagon	328 46F	↓	270 36F	
RABBIT (EUROPEAN BUILT WITH ROUND HEADLIGHTS)					
75-84	All	272 29F	↓	278 33F	

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear

VOLKSWAGEN (Continued)

RABBIT (U.S. BUILT WITH SQUARE HEADLIGHTS)

77-84	All			802 713(*)	
75-84	All				802 821
83-84	GTI	272 29F	278 33F		
79-84	Hatchback	270 58F	278 33F		
80-82	Pickup	270 58F	201 14A		

SCIROCCO

84-89	All 16V	272 29F	278 33F		
74-89	All	272 29F	278 33F		
77-88	All			802 713(*)	
75-88	All				802 821

Note: Sachs & Boge shocks are supplied with spring pl. for 78.8mm ID spring.

VOLVO

70 SERIES

97-00	C70 Coupe, S70 Sedan, V70 Wagon (Exc. AWD)	32C 100	27B 42A		
	V70 Wagon w/ AWD	32C 100			

240, 260 SERIES

75-93	All (Exc. Turbo)	323 27F	274 27F 601 600		
78-93	Turbo	110 476	274 27F 601 600		

740, 760, 780 SERIES

5/84-93	740 Sedan from ch. #81680 (Exc. Turbo 16V)	321 35F	271 82F 601 801		
	740, 760 Wagon	321 35F	271 82F 601 800		
87-92	740 Turbo 16V	321 35F	601 294		
83-4/84	740 Sedan to ch. #81679	328 70F	271 82F 601 801		
8/87-93	760, 780 Sedan w/ IRS	321 35F	601 294		
83-7/87	760, 780 Sedan w/ Solid Rear Axle	321 35F	271 82F 601 801		

* Strut Mount and Bearing

** Bearing Only

SACHS SHOCK ABSORBERS & STRUTS

Year	Model	Sachs <i>Super Gas</i>		Strut Mounts	
		Front	Rear	Front	Rear
VOLVO (Continued)					
850 SERIES					
93-97	850	32C 100	27B 42A 601 664		
940, 960 SERIES					
90-95	940, 960 Sedan w/ IRS	321 35F	601 294		
	940, 960 Sedan w/ Solid Rear Axle	321 35F	271 82F 601 801		
	940, 960 Wagon	321 35F	271 82F 601 800		

Note: When replacing nivomats with other types of shock absorbers, the rear coil springs must be replaced.

* Strut Mount and Bearing

** Bearing Only